



SMVector - Frequency Inverter Operating Instructions



| | | |
|-------------------------|--|-----------|
| 1 | Safety Information | 3 |
| 2 | Technical Data | 6 |
| 2.1 | Standards and Application Conditions..... | 6 |
| 2.2 | SMV Type Number Designation..... | 7 |
| 2.3 | Ratings..... | 8 |
| 3 | Installation | 11 |
| 3.1 | Dimensions and Mounting..... | 11 |
| 3.1.1 | NEMA 1 (IP31) Models \leq 30HP (22kW)..... | 11 |
| 3.1.2 | NEMA 1 (IP31) Models $>$ 30HP (22kW)..... | 12 |
| 3.1.3 | NEMA 4X (IP65) Models..... | 13 |
| 3.1.4 | NEMA 4X (IP65) Models with Disconnect Switch..... | 14 |
| 3.2 | Electrical Installation..... | 15 |
| 3.2.1 | Power Connections..... | 15 |
| 3.2.1.1 | Mains Connection to 120VAC Single-Phase Supply..... | 15 |
| 3.2.1.2 | Mains Connection to 240VAC Single-Phase Supply..... | 16 |
| 3.2.1.3 | Mains Connection to Three-Phase Supply..... | 16 |
| 3.2.1.4 | Motor Connection..... | 16 |
| 3.2.1.5 | Installation Recommendations for EMC Compliance..... | 17 |
| 3.2.1.6 | NEMA 4X (IP65) Input Terminal Block..... | 17 |
| 3.2.2 | Fuses/Cable Cross-Sections..... | 18 |
| 3.2.3 | Control Terminals..... | 19 |
| 4 | Commissioning | 21 |
| 4.1 | Local Keypad & Display..... | 21 |
| 4.2 | Drive Display and Modes of Operation..... | 23 |
| 4.3 | Parameter Setting..... | 24 |
| 4.4 | Electronic Programming Module (EPM)..... | 24 |
| 4.5 | Parameter Menu..... | 25 |
| 4.5.1 | Basic Setup Parameters..... | 25 |
| 4.5.2 | I/O Setup Parameters..... | 29 |
| 4.5.3 | Advanced Setup Parameters..... | 33 |
| 4.5.4 | PID Parameters..... | 36 |
| 4.5.5 | Vector Parameters..... | 38 |
| 4.5.6 | Network Parameters..... | 40 |
| 4.5.7 | Diagnostic Parameters..... | 40 |
| 4.5.7.1 | Terminal & Protection Status Display..... | 41 |
| 4.5.7.2 | Keypad Status Display..... | 41 |
| 4.5.8 | Onboard Communications Parameters 15-30HP (11-22kW)..... | 42 |
| 5 | Troubleshooting and Diagnostics | 43 |
| 5.1 | Status/Warning Messages..... | 43 |
| 5.2 | Drive Configuration Messages..... | 44 |
| 5.3 | Fault Messages..... | 44 |
| Appendix A | | 47 |
| A.1 | Permissible Cable Lengths..... | 47 |



About These Instructions

This documentation applies to the SMV frequency inverter and contains important technical data regarding the installation, operation, and commissioning of the inverter.

These instructions are only valid for SMV frequency inverters with software revision 2.0 or higher (refer to drive nameplate, an example is shown below).

Please read these instructions in their entirety before commissioning the drive.

| | | | | | |
|---|--|--|--|---|---|
| A | B | C | D | E | F |
| Lenze AC Tech Made in USA Inverter SMV ector | Type: ESV751N04TXB Id-No: 00000000 | INPUT: 3 (3/PE) 400/480 V 2.9/2.5 A 50-60 HZ | OUTPUT: 3 (3/PE) 0 - 400/460 V 2.4/2.1 A 0.75 KW/1HP 0 - 500 HZ | For detailed information refer to instruction Manual: SV01 00000000000000000000 ESV751N04TXB000XX### | |
| | LISTED 5081 US IND. CONT. EQ. | TYPE-4X INDOOR USE ONLY | | | |

| A | B | C | D | E | F |
|----------------|------|---------------|----------------|------------------|------------------|
| Certifications | Type | Input Ratings | Output Ratings | Hardware Version | Software Version |

| Scope of delivery | Important |
|--|---|
| <ul style="list-style-type: none"> • 1 SMV Inverter with EPM installed (see Section 4.4) • 1 Operating Instructions manual | <p>After receipt of the delivery, check immediately whether the items delivered match the accompanying papers. Lenze AC Tech does not accept any liability for deficiencies claimed subsequently.</p> <p>Claim:</p> <ul style="list-style-type: none"> • visible transport damage immediately to the forwarder. • visible deficiencies /incompleteness immediately to your Lenze AC Tech representative |

Copyright © 2006 Lenze AC Tech Corporation

All rights reserved. No part of this manual may be reproduced or transmitted in any form without written permission from Lenze AC Tech Corporation. The information and technical data in this manual are subject to change without notice. Lenze AC Tech Corporation makes no warranty of any kind with respect to this material, including, but not limited to, the implied warranties of its merchantability and fitness for a given purpose. Lenze AC Tech Corporation assumes no responsibility for any errors that may appear in this manual.

All information given in this documentation has been carefully selected and tested for compliance with the hardware and software described. Nevertheless, discrepancies cannot be ruled out. Lenze AC Tech does not accept any responsibility nor liability for damages that may occur. Any necessary corrections will be implemented in subsequent editions. This document is printed in the United States



1 Safety Information

General

Some parts of Lenze AC Tech controllers can be electrically live and some surfaces can be hot. Non-authorized removal of the required cover, inappropriate use, and incorrect installation or operation creates the risk of severe injury to personnel and/or damage to equipment.

All operations concerning transport, installation, and commissioning as well as maintenance must be carried out by qualified, skilled personnel who are familiar with the installation, assembly, commissioning, and operation of variable frequency drives and the application for which it is being used.

Installation

Ensure proper handling and avoid excessive mechanical stress. Do not bend any components and do not change any insulation distances during transport, handling, installation or maintenance. Do not touch any electronic components or contacts. This drive contains electrostatically sensitive components, which can easily be damaged by inappropriate handling. Static control precautions must be adhered to during installation, testing, servicing and repairing of this drive and associated options. Component damage may result if proper procedures are not followed.

To ensure proper operation, do not install the drive where it is subjected to adverse environmental conditions such as combustible, oily, or hazardous vapors; corrosive chemicals; excessive dust, moisture or vibration; direct sunlight or extreme temperatures.

This drive has been tested by Underwriters Laboratory (UL) and is UL Listed in compliance with the UL508C Safety Standard. This drive must be installed and configured in accordance with both national and international standards. Local codes and regulations take precedence over recommendations provided in this and other Lenze AC Tech documentation.

The SMVVector drive is considered a component for integration into a machine or process. It is neither a machine nor a device ready for use in accordance with European directives (reference machinery directive and electromagnetic compatibility directive). It is the responsibility of the end user to ensure that the machine meets the applicable standards.

Electrical Connection

When working on live drive controllers, applicable national safety regulations must be observed. The electrical installation must be carried out according to the appropriate regulations (e.g. cable cross-sections, fuses, protective earth [PE] connection). While this document does make recommendations in regards to these items, national and local codes must be adhered to.

The documentation contains information about installation in compliance with EMC (shielding, grounding, filters and cables). These notes must also be observed for CE-marked controllers. The manufacturer of the system or machine is responsible for compliance with the required limit values demanded by EMC legislation.

Application

The drive must not be used as a safety device for machines where there is a risk of personal injury or material damage. Emergency Stops, over-speed protection, acceleration and deceleration limits, etc must be made by other devices to ensure operation under all conditions.

The drive does feature many protection devices that work to protect the drive and the driven equipment by generating a fault and shutting the drive and motor down by removing power. Mains power variances can also result in shutdown of the drive. When the fault condition disappears or is cleared, the drive can be configured to automatically restart, it is the responsibility of the user, OEM and/or integrator to ensure that the drive is configured for safe operation.



Safety Information

Explosion Proof Applications

Explosion proof motors that are not rated for inverter use lose their certification when used for variable speed. Due to the many areas of liability that may be encountered when dealing with these applications, the following statement of policy applies:

Lenze AC Tech Corporation inverter products are sold with no warranty of fitness for a particular purpose or warranty of suitability for use with explosion proof motors. Lenze AC Tech Corporation accepts no responsibility for any direct, incidental or consequential loss, cost or damage that may arise through the use of AC inverter products in these applications. The purchaser expressly agrees to assume all risk of any loss, cost or damage that may arise from such application.

Operation

Systems including controllers must be equipped with additional monitoring and protection devices according to the corresponding standards (e.g. technical equipment, regulations for prevention of accidents, etc.). The controller may be adapted to your application as described in this documentation.



DANGER!

- After the controller has been disconnected from the supply voltage, live components and power connection must not be touched immediately, since capacitors could be charged. Please observe the corresponding notes on the controller.
- Close all protective covers and doors prior to and during operation.
- Do not cycle input power to the controller more than once every two minutes.
- For SMVector models that are equipped with a Disconnect Switch (11th character in model number is L or M), the Disconnect Switch is intended as a motor service disconnect and does not provide branch circuit protection to the inverter or motor. When servicing the motor, it is necessary to wait 3 minutes after turning this switch to the off position before working on motor power wiring as the inverter stores electrical power. To service the inverter, it is necessary to remove mains ahead of the drive and wait 3 minutes.

Safety Notifications

All safety information given in these Operating Instructions includes a visual icon, a bold signal word and a description.



Signal Word! (characterizes the severity of the danger)

NOTE (describes the danger and informs on how to proceed)

| Icon | | Signal Words | |
|------|---|---------------------------------------|---|
| | Warning of hazardous electrical voltage | DANGER! | Warns of impending danger. Consequences if disregarded: Death or severe injuries. |
| | Warning of a general danger | WARNING! | Warns of potential, very hazardous situations. Consequences if disregarded: Death or severe injuries. |
| | Warning of hot surface and risk of burn | WARNING! Hot Surface | Warns of potential, serious situations. Labels may be on or inside the equipment to alert people that surfaces may reach dangerous temperatures. |
| | Warning of damage to equipment | STOP! | Warns of potential damage to material and equipment. Consequences if disregarded: Damage to the controller/drive or its environment. |
| | Information | NOTE | Designates a general, useful note. If observed, then using the controller/drive system is made easier. |



Harmonics Notification in accordance with EN 61000-3-2, EN 61000-3-12:

Operation in public supply networks (Limitation of harmonic currents i.a.w. EN 61000-3-2, Electromagnetic Compatibility (EMC) Limits). Limits for harmonic current emissions (equipment input current up to 16A/phase).

| Directive | Total Power connected to Mains (public supply) | Additional Measures Required for Compliance ⁽²⁾ |
|---------------|--|---|
| EN 61000-3-2 | < 0.5kW | with mains choke |
| | 0.5 ... 1kW | with active filter |
| | > 1kW | complies without additional measures |
| EN 61000-3-12 | 16 ... 75amp | Additional measures are required for compliance with the standard |

- (1) For compliance with EMC regulations, the permissible cable lengths may change.
- (2) The additional measures described only ensure that the controller meets the requirements of the EN 61000-3-2. The machine/system manufacturer is responsible for the machine's compliance with the regulations.

Safety Information in accordance with EN 61800-5-1:



DANGER! Hazard of Electrical Shock

Capacitors retain charge for approximately 180 seconds after power is removed. Allow at least 3 minutes for discharge of residual charge before touching the drive.



WARNING!

- This product can cause a d.c. current in the PE conductor. Where a residual current-operated (RCD) or monitoring (RCM) device is used for protection in case of direct or indirect contact, only an RCD or RCM Type B is allowed on the supply side of this product.
- Leakage Current may exceed 3.5mA AC. The minimum size of the PE conductor shall comply with local safety regulations for high leakage current equipment.
- In a domestic environment, this product may cause radio interference in which case supplementary mitigation measures may be required.



NOTE

Control and communications terminals provide reinforced insulation when the drive is connected to a power system rated up to 300V rms between phase to ground (PE) and the applied voltage on Terminals 16 and 17 is less than 150VAC between phase and ground.

Control and communications terminals provide basic insulation when the drive is connected to a power system rated up to 300V between phase to ground (PE) and the applied voltage on terminals 16 and 17 is less than 250 VAC between phase phase and ground (PE).

Safety Information in accordance with UL:

Note for UL approved system with integrated controllers: UL warnings are notes which apply to UL systems. The documentation contains special information about UL.



Warnings!

- Suitable for use on a circuit capable of delivering not more than 200,000 rms symmetrical amperes, at the maximum voltage rating marked on the drive.
- Use minimum 75 °C copper wire only.
- Shall be installed in a pollution degree 2 macro-environment.
- NEMA 1 (IP31) models shall be installed in a pollution degree 2 macro-environment.
- All models are suitable for installation in a compartment handling Conditioned Air.


Torque Requirements (in accordance with UL) are listed in section 3.2.1, Power Connections.



Technical Data

2 Technical Data

2.1 Standards and Application Conditions

| | | |
|--|--|--|
| Conformity | CE | Low Voltage (2006/95/EC) & EMC (2004/108/EC) Directives |
| Approvals | UL508C | Underwriters Laboratories -Power Conversion Equipment |
| Input voltage phase imbalance | ≤ 2% | |
| Humidity | ≤ 95% non-condensing | |
| Temperature range | Transport | -25 ... +70°C |
| | Storage | -20 ... +70°C |
| | Operation | -10 ... +55°C (with 2.5%/°C current derating above +40°C) |
| Installation height | 0 - 4000m a.m.s.l. | (with 5%/1000 m current derating above 1000m a.m.s.l.) |
| Vibration resistance | acceleration resistant up to 1.0g | |
|  Earth leakage current | > 3.5 mA to PE | |
| Max Permissible Cable Length ⁽¹⁾ | <= 4.0 Hp (3.0 kW) | 30 meters shielded, 60 meters un-shielded |
| | > 5.0 Hp (3.7 kW) | 50 meters shielded, 100 meters un-shielded. |
| Enclosure | IP31/NEMA 1 | IP65/NEMA 4X |
| | NEMA 1 and NEMA 4X model enclosures are plenum rated in accordance with UL 508C and are suitable for installation in a compartment handling conditioned air. | |
| Protection measures against | short circuit, earth fault, phase loss, over voltage, under voltage, motor stalling, over temperature, motor overload | |
| Compliance with EN 61000-3-2 Requirements ⁽²⁾ | < 0.5kW | with mains choke |
| | 0.5 ... 1kW | with active filter |
| | > 1kW | without additional measures |
| Compliance with EN 61000-3-12 Requirements ⁽²⁾ | 16 ... 75amp | Additional measures required for compliance with EN 61000-3-12 |

Operation in public supply networks (Limitation of harmonic currents i.a.w. EN 61000-3-2, Electromagnetic Compatibility (EMC) Limits). Limits for harmonic current emissions (equipment input current up to 16A/phase).

(1) The stated cable lengths are permissible at default carrier frequencies (refer to parameter P166).

(2) The additional measures described only ensure that the controller meets the requirements of the EN 61000-3-2. The machine/system manufacturer is responsible for the machine's compliance with the regulations.



2.2 SMV Type Number Designation

The table herein describes the Type numbering designation for the SMVector Inverter models.

| Electrical Products in the SMVector Series | ESV | 152 | NO | 2 | T | X | B |
|---|-----|-------------------------------------|----|---|---|---|---|
| Power Rating in kW: | | | | | | | |
| 251 = 0.25kW (0.33HP) | | 113 = 11.0kW (15HP) | | | | | |
| 371 = 0.37kW (0.5HP) | | 153 = 15.0kW (20HP) | | | | | |
| 751 = 0.75kW (1HP) | | 183 = 18.5kW (25HP) | | | | | |
| 112 = 1.1kW (1.5HP) | | 223 = 22.0kW (30HP) | | | | | |
| 152 = 1.5kW (2HP) | | 303 = 30.0kW (40HP) | | | | | |
| 222 = 2.2kW (3HP) | | 373 = 37.5kW (50HP) | | | | | |
| 302 = 3.0kW (4HP) | | 453 = 45.0kW (60HP) | | | | | |
| 402 = 4.0kW (5HP) | | | | | | | |
| 552 = 5.5kW (7.5HP) | | | | | | | |
| 752 = 7.5kW (10HP) | | | | | | | |
| Installed I/O & Communication Module(s): | | | | | | | |
| C_ = CANopen (Available all models) | | The "_" blank can be: | | | | | |
| D_ = DeviceNet (Available all models) | | 0 = Standard Keypad | | | | | |
| E_ = Ethernet/IP, ModBus TCP/IP (Avail all models) | | N = No Keypad (NEMA 4X / IP65 only) | | | | | |
| R_ = RS-485 / ModBus /Lecom (Avail all models) | | | | | | | |
| P_ = ProfiBus-DP (Available all models) | | | | | | | |
| N_ = No Communications installed (Non-IP20) | | | | | | | |
| Input Voltage: | | | | | | | |
| 1 = 120 VAC (doubler output) or 240 VAC | | | | | | | |
| 2 = 240 VAC | | | | | | | |
| 4 = 400/480 VAC | | | | | | | |
| 6 = 600 VAC | | | | | | | |
| Input Phase: | | | | | | | |
| S = Single Phase Input only | | | | | | | |
| Y = Single or Three Phase Input | | | | | | | |
| T = Three Phase Input only | | | | | | | |
| Input Line Filter | | | | | | | |
| F = Integral EMC Filter | | | | | | | |
| L = Integral EMC Filter and Integrated Disconnect Switch (NEMA 4X/IP65 Models only) | | | | | | | |
| M = Integrated Disconnect Switch (NEMA 4X/IP65 Models only) | | | | | | | |
| X = No EMC Filter/ No Disconnect Switch | | | | | | | |
| Enclosure: | | | | | | | |
| B = NEMA 1/IP31; Indoor only | | | | | | | |
| C = NEMA 4X/IP65; Indoor only; Convection cooled | | | | | | | |
| D = NEMA 4X/IP65; Indoor only; Fan cooled | | | | | | | |
| E = NEMA 4X/IP65; Indoor/Outdoor; Convection cooled | | | | | | | |
| F = NEMA 4X/IP65; Indoor/Outdoor; Fan cooled | | | | | | | |



NOTE

Prior to installation make sure the enclosure is suitable for the end-use environment

Variables that influence enclosure suitability include (but are not limited to) temperature, airborne contaminants, chemical concentration, mechanical stress and duration of exposure (sunlight, wind, precipitation).



Technical Data

2.3 Ratings

120V / 240VAC Models

| Mains = 120V Single Phase (1/N/PE) (90...132V), 240V Single Phase (2/PE) (170...264V); 48...62Hz | | | | | | | | | |
|--|-------|------|---------------|-----------|-----------------------------|------------|-------------------|-----------------------|-----------------------|
| Type | Power | | Mains Current | | Output Current | | Heat Loss (Watts) | | |
| | Hp | kW | 120V A | 240V A | Cont (I _n) A | Max I % | N1/IP31 | N4X/IP65 No filter | N4X/IP65 W/ filter |
| ESV251--1S-- | 0.33 | 0.25 | 6.8 | 3.4 | 1.7 | 200 | 24 | | |
| ESV371--1S-- | 0.5 | 0.37 | 9.2 | 4.6 | 2.4 | 200 | 32 | 32 | |
| ESV751--1S-- | 1 | 0.75 | 16.6 | 8.3 | 4.2 | 200 | 52 | 41 | |
| ESV112--1S-- | 1.5 | 1.1 | 20 | 10.0 | 6.0 | 200 | 74 | 74 | |

NOTES:

Output Current: The Output Current Maximum (%) is a percentage of the Output Current Continuous Amps (I_n) rating and is adjustable in parameter P171.

240VAC Models

| Mains = 240V Single Phase (2/PE) (170...264V); 48...62Hz | | | | | | | | | |
|--|-------|------|---------------|--|-----------------------------|------------|-------------------|-----------------------|-----------------------|
| Type | Power | | Mains Current | | Output Current | | Heat Loss (Watts) | | |
| | Hp | kW | 240V A | | Cont (I _n) A | Max I % | N1/IP31 | N4X/IP65 No filter | N4X/IP65 W/ filter |
| ESV251--2S-- | 0.33 | 0.25 | 3.4 | | 1.7 | 200 | 20 | | |
| ESV371--2S-- | 0.5 | 0.37 | 5.1 | | 2.4 | 200 | | | 30 |
| ESV751--2S-- | 1 | 0.75 | 8.8 | | 4.2 | 200 | | | 42 |
| ESV112--2S-- | 1.5 | 1.1 | 12.0 | | 6.0 | 200 | | | 63 |
| ESV152--2S-- | 2 | 1.5 | 13.3 | | 7.0 | 200 | | | 73 |
| ESV222--2S-- | 3 | 2.2 | 17.1 | | 9.6 | 200 | | | 97 |

| 240V Single Phase (2/PE) (170...264V), 240V Three Phase (3/PE) (170...264V); 48...62Hz | | | | | | | | | |
|--|-------|------|----------------|----------------|-----------------------------|------------|-------------------|-----------------------|-----------------------|
| Type | Power | | Mains Current | | Output Current | | Heat Loss (Watts) | | |
| | Hp | kW | 1- (2/PE) A | 3- (3/PE) A | Cont (I _n) A | Max I % | N1/IP31 | N4X/IP65 No filter | N4X/IP65 W/ filter |
| ESV371--2Y-- | 0.5 | 0.37 | 5.1 | 2.9 | 2.4 | 200 | 27 | 26 | |
| ESV751--2Y-- | 1 | 0.75 | 8.8 | 5.0 | 4.2 | 200 | 41 | 38 | |
| ESV112--2Y-- | 1.5 | 1.1 | 12.0 | 6.9 | 6.0 | 200 | 64 | 59 | |
| ESV152--2Y-- | 2 | 1.5 | 13.3 | 8.1 | 7.0 | 200 | 75 | 69 | |
| ESV222--2Y-- | 3 | 2.2 | 17.1 | 10.8 | 9.6 | 200 | 103 | 93 | |



| 240V Three Phase (3/PE) (170...264V); 48...62Hz | | | | | | | | | |
|---|-------|-----|---------------|-----------------------------|----------------|---------|-----------------------|-----------------------|--|
| Type | Power | | Mains Current | | Output Current | | Heat Loss (Watts) | | |
| | Hp | kW | 240V A | Cont (I _n) A | Max I % | N1/IP31 | N4X/IP65 No filter | N4X/IP65 W/ filter | |
| ESV112--2T-- | 1.5 | 1.1 | 6.9 | 6 | 200 | 64 | | | |
| ESV152--2T-- | 2 | 1.5 | 8.1 | 7 | 200 | 75 | | | |
| ESV222--2T-- | 3 | 2.2 | 10.8 | 9.6 | 200 | 103 | | | |
| ESV402--2T-- | 5 | 4.0 | 18.6 | 16.5 | 200 | 154 | 139 | | |
| ESV552--2T-- | 7.5 | 5.5 | 26 | 23 | 200 | 225 | 167 | | |
| ESV752--2T-- | 10 | 7.5 | 33 | 29 | 200 | 274 | 242 | | |
| ESV113--2T-- | 15 | 11 | 48 | 42 | 180 | 485 | 468 | | |
| ESV153--2T-- | 20 | 15 | 59 | 54 | 180 | 614 | 591 | | |

NOTES:

Output Current: The Output Current Maximum (%) is a percentage of the Output Current Continuous Amps (In) rating and is adjustable in parameter P171.

400...480VAC Models

| 400 ... 480V Three Phase (3/PE) (400V: 340...440V), (480V: 340...528V); 48...62Hz | | | | | | | | | | | |
|---|-------|------|---------------|-----------|-----------------------------|------|------------|------|-------------------|-----------------------|-----------------------|
| Type | Power | | Mains Current | | Output Current | | | | Heat Loss (Watts) | | |
| | Hp | kW | 400V A | 480V A | Cont (I _n) A | | Max I % | | N1/IP31 | N4X/IP65 No filter | N4X/IP65 W/ filter |
| | | | | | 400V | 480V | 400V | 480V | | | |
| ESV371--4T-- | 0.5 | 0.37 | 1.7 | 1.5 | 1.3 | 1.1 | 175 | 200 | 23 | 21 | 25 |
| ESV751--4T-- | 1 | 0.75 | 2.9 | 2.5 | 2.4 | 2.1 | 175 | 200 | 37 | 33 | 37 |
| ESV112--4T-- | 1.5 | 1.1 | 4.2 | 3.6 | 3.5 | 3.0 | 175 | 200 | 48 | 42 | 46 |
| ESV152--4T-- | 2 | 1.5 | 4.7 | 4.1 | 4.0 | 3.5 | 175 | 200 | 57 | 50 | 54 |
| ESV222--4T-- | 3 | 2.2 | 6.1 | 5.4 | 5.5 | 4.8 | 175 | 200 | 87 | 78 | 82 |
| ESV302--4T-- | 4 | 3.0 | 8.3 | 7.0 | 7.6 | 6.3 | 175 | 200 | | | 95 |
| ESV402--4T-- | 5 | 4.0 | 10.6 | 9.3 | 9.4 | 8.2 | 175 | 200 | 128 | 103 | 111 |
| ESV552--4T-- | 7.5 | 5.5 | 14.2 | 12.4 | 12.6 | 11.0 | 175 | 200 | 178 | 157 | 165 |
| ESV752--4T-- | 10 | 7.5 | 18.1 | 15.8 | 16.1 | 14.0 | 175 | 200 | 208 | 190 | 198 |
| ESV113--4T-- | 15 | 11 | 27 | 24 | 24 | 21 | 155 | 180 | 418 | 388 | 398 |
| ESV153--4T-- | 20 | 15 | 35 | 31 | 31 | 27 | 155 | 180 | 493 | 449 | 459 |
| ESV183--4T-- | 25 | 18.5 | 44 | 38 | 39 | 34 | 155 | 180 | 645 | 589 | 600 |
| ESV223--4T-- | 30 | 22 | 52 | 45 | 46 | 40 | 155 | 180 | 709 | 637 | 647 |
| ESV303--4T-- | 40 | 30 | 68 | 59 | 60 | 52 | | 180 | 1020 | | |
| ESV373--4T-- | 50 | 37.5 | 85 | 74 | 75 | 65 | | 180 | 1275 | | |
| ESV453--4T-- | 60 | 45 | 100 | 87 | 88 | 77 | | 180 | 1530 | | |

NOTES:

Output Current: The Output Current Maximum (%) is a percentage of the Output Current Continuous Amps (In) rating and is adjustable in parameter P171.

For 400...480 VAC models, the output current maximum (%) in the 400V column is used when P107 = 0

For 400...480 VAC models, the output current maximum (%) in the 480V column is used when P107 = 1



Technical Data

600VAC Models

| 600V Three Phase (3/PE) (425...660V); 48...62Hz | | | | | | | | |
|---|-------|------|---------------|-----------------------------|------------|-------------------|-----------------------|-----------------------|
| Type | Power | | Mains Current | Output Current | | Heat Loss (Watts) | | |
| | Hp | kW | A | Cont (I _n) A | Max I % | N1/IP31 | N4X/IP65 No filter | N4X/IP65 W/ filter |
| ESV751--6T-- | 1 | 0.75 | 2 | 1.7 | 200 | 37 | 31 | |
| ESV152--6T-- | 2 | 1.5 | 3.2 | 2.7 | 200 | 51 | 43 | |
| ESV222--6T-- | 3 | 2.2 | 4.4 | 3.9 | 200 | 68 | 57 | |
| ESV402--6T-- | 5 | 4 | 6.8 | 6.1 | 200 | 101 | 67 | |
| ESV552--6T-- | 7.5 | 5.5 | 10.2 | 9 | 200 | 148 | 116 | |
| ESV752--6T-- | 10 | 7.5 | 12.4 | 11 | 200 | 172 | 152 | |
| ESV113--6T-- | 15 | 11 | 19.7 | 17 | 180 | 380 | 356 | |
| ESV153--6T-- | 20 | 15 | 25 | 22 | 180 | 463 | 431 | |
| ESV183--6T-- | 25 | 18.5 | 31 | 27 | 180 | 560 | 519 | |
| ESV223--6T-- | 30 | 22 | 36 | 32 | 180 | 640 | 592 | |
| ESV303--6T-- | 40 | 30 | 47 | 41 | 180 | 930 | | |
| ESV373--6T-- | 50 | 37.5 | 59 | 52 | 180 | 1163 | | |
| ESV453--6T-- | 60 | 45 | 71 | 62 | 180 | 1395 | | |

NOTES:

Output Current: The Output Current Maximum (%) is a percentage of the Output Current Continuous Amps (I_n) rating and is adjustable in parameter P171.



STOP!

- For installations above 1000m a.m.s.l., derate I_n by 5% per 1000m, do not exceed 4000m a.m.s.l.
- Operation above 40°C, derate I_n by 2.5% per °C, do not exceed 55°C.

Output Current (I_n) derating for Carrier Frequency (P166) for NEMA 1 (IP31) Models:

- If P166=2 (8 kHz), derate I_n to 92% of drive rating
- If P166=3 (10 kHz), derate I_n to 84% of drive rating

Output Current (I_n) derating for Carrier Frequency (P166) for NEMA 4X (IP65) Models:

- If P166=1 (6 kHz), derate I_n to 92% of drive rating
- If P166=2 (8 kHz), derate I_n to 84% of drive rating
- If P166=3 (10 kHz), derate I_n to 76% of drive rating



3 Installation


3.1 Dimensions and Mounting



WARNING!

Drives must not be installed where subjected to adverse environmental conditions such as: combustible, oily, or hazardous vapors; corrosive chemicals; excessive dust, moisture or vibration; direct sunlight or extreme temperatures.

3.1.1 NEMA 1 (IP31) Models ≤ 30HP (22kW)




| | Type | a in (mm) | a1 in (mm) | b in (mm) | b1 in (mm) | b2 in (mm) | c in (mm) | s1 in (mm) | s2 in (mm) | m lb (kg) |
|----|--|--------------|---------------|--------------|---------------|---------------|--------------|---------------|---------------|--------------|
| G1 | ESV251-----B; ESV371-----B ESV751-----B | 3.90 (99) | 3.12 (79) | 7.48 (190) | 7.00 (178) | 0.24 (6) | 4.35 (111) | 0.6 (15) | 2.0 (50) | 2.0 (0.9) |
| G2 | ESV112-----B; ESV152-----B ESV222-----B | 3.90 (99) | 3.12 (79) | 7.52 (191) | 7.00 (178) | 0.26 (7) | 5.45 (138) | 0.6 (15) | 2.0 (50) | 2.8 (1.3) |
| G3 | ESV402-----B | 3.90 (99) | 3.12 (79) | 7.52 (191) | 7.00 (178) | 0.30 (8) | 5.80 (147) | 0.6 (15) | 2.0 (50) | 3.2 (1.5) |
| H1 | ESV552-----B; ESV752-----B | 5.12 (130) | 4.25 (108) | 9.83 (250) | 9.30 (236) | 0.26 (7) | 6.30 (160) | 0.6 (15) | 2.0 (50) | 6.0 (2.0) |
| J1 | ESV113-----B; ESV153-----B ESV183-----B; ESV223-----B | 6.92 (176) | 5.75 (146) | 12.50 (318) | 11.88 (302) | 0.31 (8) | 8.09 (205) | 0.6 (15) | 2.0 (50) | 13.55 (6.15) |

| Conduit Hole Dimensions | Type | N | P | P1 | Q | S |
|-------------------------|------|-----------|------------|----------|-----------|-----------------------|
| | | in (mm) | in (mm) | in (mm) | in (mm) | in (mm) |
| | G1 | 1.84 (47) | 1.93 (49) | .70 (18) | 1.00 (25) | .88 (22) |
| | G2 | 1.84 (47) | 3.03 (77) | .70 (18) | 1.00 (25) | .88 (22) |
| | G3 | 1.84 (47) | 3.38 (86) | .70 (18) | 1.00 (25) | .88 (22) |
| | H1 | 2.46 (62) | 3.55 (90) | .13 (3) | 1.38 (35) | 1.13 (29) .88 (22) |
| | J1 | 3.32 (84) | 4.62 (117) | .73 (19) | 1.40 (36) | 1.31 (33) |
| | | | | | | .88 (22) |



Installation

3.1.2 NEMA 1 (IP31) Models > 30HP (22kW)




| | Type | a in (mm) | a1 in (mm) | b in (mm) | b1 in (mm) | b2 in (mm) | c in (mm) | s1 in (mm) | s2 in (mm) | m lb (kg) |
|----|-------------------------------|--------------|---------------|--------------|---------------|---------------|--------------|---------------|---------------|--------------|
| K1 | ESV303--4--B; ESV303--6--B | 8.72 (221) | 7.50 (190) | 14.19 (360) | 13.30 (338) | 0.45 (11.4) | 10.07 (256) | 0.6 (15) | 2.0 (50) | 24 (10.9) |
| K2 | ESV373--4--B; ESV373--6--B | 8.72 (221) | 7.50 (190) | 17.19 (436) | 16.30 (414) | 0.45 (11.4) | 10.07 (256) | 0.6 (15) | 2.0 (50) | 31 (14.1) |
| K3 | ESV453--4--B ESV453--6--b | 8.72 (221) | 7.50 (190) | 20.19 (513) | 19.30 (490) | 0.45 (11.4) | 10.07 (256) | 0.6 (15) | 2.0 (50) | 35 (15.9) |

| | Type | Conduit Hole Dimensions | | | | | |
|--|------|-------------------------|--------------|---------------|--------------|--------------|---------------|
| | | N in (mm) | P in (mm) | P1 in (mm) | Q in (mm) | S in (mm) | S1 in (mm) |
| | K1 | 3.75 (95) | 5.42 (137) | 1.50 (38.1) | 1.75 (44.4) | 1.75 (44.4) | 0.875 (22.2) |
| | K2 | 3.75 (95) | 5.42 (137) | 1.50 (38.1) | 1.75 (44.4) | 1.75 (44.4) | 0.875 (22.2) |
| | K3 | 3.75 (95) | 5.42 (137) | 1.50 (38.1) | 1.75 (44.4) | 1.75 (44.4) | 0.875 (22.2) |



3.1.3 NEMA 4X (IP65) Models



| | Type | a in (mm) | a1 in (mm) | b in (mm) | b1 in (mm) | b2 in (mm) | c in (mm) | s1 in (mm) | s2 in (mm) | m lb (kg) |
|----|--|--------------|---------------|--------------|---------------|---------------|--------------|---------------|---------------|--------------|
| R1 | ESV371N01SX-; ESV751N01SX-; ESV371N02YX-; ESV751N02YX-; ESV371N04TX-; ESV751N04TX-; ESV751N06TX-; ESV371N02SF-; ESV751N02SF-; ESV371N04TF-; ESV751N04TF- | 6.28 (160) | 5.90 (150) | 8.00 (203) | 6.56 (167) | 0.66 (17) | 4.47 (114) | 2.00 (51) | 2.00 (51) | 3.6 (1.63) |
| R2 | ESV112N01SX-; ESV112N02YX-; ESV152N02YX-; ESV112N04TX-; ESV152N04TX-; ESV222N04TX-; ESV152N06TX-; ESV222N06TX-; ESV112N02SF-; ESV152N02SF-; ESV112N04TF-; ESV152N04TF-; ESV222N04TF-; ESV302N04TF- | 6.28 (160) | 5.90 (150) | 8.00 (203) | 6.56 (167) | 0.66 (17) | 6.31 (160) | 2.00 (51) | 2.00 (51) | 5.9 (2.68) |
| S1 | ESV222N02YX-; ESV222N02SF- | 7.12 (181) | 6.74 (171) | 8.00 (203) | 6.56 (167) | 0.66 (17) | 6.77 (172) | 2.00 (51) | 2.00 (51) | 7.1 (3.24) |
| T1 | ESV552N02TX-; ESV752N02TX- ESV752N04TX-; ESV752N06TX- ESV752N04TF- | 8.04 (204) | 7.56 (192) | 10.00 (254) | 8.04 (204) | 0.92 (23) | 8.00 (203) | 4.00 (102) | 4.00 (102) | 10.98 (4.98) |
| V1 | ESV402N02TX-; ESV402N04TX-; ESV552N04TX-; ESV402N06TX-; ESV552N06TX-; ESV402N04TF-; ESV552N04TF- | 8.96 (228) | 8.48 (215) | 10.00 (254) | 8.04 (204) | 0.92 (23) | 8.00 (203) | 4.00 (102) | 4.00 (102) | 11.58 (5.25) |
| W1 | ESV113N02TX-; ESV153N02TX- ESV113N04TX-; ESV153N04TX- ESV113N04TF-; ESV153N04TF- ESV113N06TX-; ESV153N06TX- ESV183N04TX-; ESV183N04TF- ESV183N06TX- | 9.42 (240) | 8.94 (228) | 14.50 (368) | 12.54 (319) | 0.92 (24) | 9.45 (241) | 4.00 (102) | 4.00 (102) | 22.0 (10.0) |
| X1 | ESV223N04TX-; ESV223N04TF- ESV223N06TX- | 9.42 (240) | 8.94 (228) | 18.5 (470) | 16.54 (420) | 0.92 (24) | 9.45 (241) | 4.00 (102) | 4.00 (102) | 25.5 (11.6) |

_ = Last digit of part number:

C = N4X Indoor (convection cooled)

E = N4X In/Outdoor (convection cooled)

~ = Last digit of part number: D = N4X Indoor (fan cooled)


F = N4X In/Outdoor (fan cooled)

| Conduit Hole Dimensions | | Type | N in (mm) | P in (mm) | Q in (mm) | S in (mm) | S1 in (mm) |
|-------------------------|----|------------|--------------|--------------|--------------|--------------|---------------|
| | | R1 | 3.14 (80) | 2.33 (59) | 1.50 (38) | .88 (22) | n/a |
| | | R2 | 3.14 (80) | 4.18 (106) | 1.50 (38) | .88 (22) | n/a |
| | S1 | 3.56 (90) | 4.63 (118) | 1.50 (38) | .88 (22) | n/a | |
| | T1 | 4.02 (102) | 5.00 (127) | 1.85 (47) | 1.06 (27) | n/a | |
| | V1 | 4.48 (114) | 5.00 (127) | 1.85 (47) | 1.06 (27) | n/a | |
| | W1 | 4.71 (120) | 5.70 (145) | 2.00 (51) | 1.375 (35) | 1.125 (28) | |
| | X1 | 4.71 (120) | 5.70 (145) | 2.00 (51) | 1.375 (35) | 1.125 (28) | |



Installation

3.1.4 NEMA 4X (IP65) Models with Disconnect Switch



| | Type | a in (mm) | a1 in (mm) | b in (mm) | b1 in (mm) | b2 in (mm) | c in (mm) | c1 in (mm) | s1 in (mm) | s2 in (mm) | m lb (kg) | | |
|-----|--|---|---|-----------------|------------------|------------------|-----------------|------------------|------------------|------------------|-----------------|----------------|----------------|
| AA1 | ESV371N01SM_ ; ESV371N02YM_ ; ESV371N02SL_ ; ESV371N04TM_ ; ESV371N04TL_ ; ESV371N06TM_ ; ESV751N01SM_ ; ESV751N02YM_ ; ESV751N02SL_ ; ESV751N04TM_ ; ESV751N04TL_ ; ESV751N06TM_ ; | 6.28 (160) | 5.90 (150) | 10.99 (279) | 9.54 (242) | 0.66 (17) | 4.47 (114) | .86 (22) | 2.00 (51) | 2.00 (51) | 4.7 (2.13) | | |
| | AA2 | ESV112N01SM_ ; ESV112N02YM_ ; ESV112N02SL_ ; ESV112N04TM_ ; ESV112N04TL_ ; ESV152N02YM_ ; ESV152N02SL_ ; ESV152N04TM_ ; ESV152N04TL_ ; ESV152N06TM_ ; ESV222N04TM_ ; ESV222N04TL_ ; ESV222N06TM_ ; ESV302N04TL_ ; | 6.28 (160) | 5.90 (150) | 10.99 (279) | 9.54 (242) | 0.66 (17) | 6.31 (160) | .86 (22) | 2.00 (51) | 2.00 (51) | 7.9 (3.58) | |
| | | AD1 | ESV222N02SL_ ; ESV222N02YM_ ; | 7.12 (181) | 6.74 (171) | 10.99 (279) | 9.54 (242) | 0.66 (17) | 6.77 (172) | .86 (22) | 2.00 (51) | 2.00 (51) | 9.0 (4.08) |
| | | AB1 | ESV552N02TM_ ; ESV752N02TM_ ; ESV752N04TM_ ; ESV752N06TM_ ; ESV752N04TL_ ; | 8.04 (204) | 7.56 (192) | 13.00 (330) | 11.04 (280) | 0.92 (23) | 8.00 (203) | .86 (22) | 4.00 (102) | 4.00 (102) | 13.9 (6.32) |
| | | AC1 | ESV402N02TM_ ; ESV402N04TM_ ; ESV552N04TM_ ; ESV402N06TM_ ; ESV552N06TM_ ; ESV402N04TL_ ; ESV552N04TL_ ; | 8.96 (228) | 8.48 (215) | 13.00 (330) | 11.04 (280) | 0.92 (23) | 8.04 (204) | .86 (22) | 4.00 (102) | 4.00 (102) | 14.7 (6.66) |
| AE1 | | ESV113N04TM_ ; ESV153N04TM_ ; ESV113N06TM_ ; ESV153N06TM_ ; | 9.42 (240) | 8.94 (228) | 14.50 (368) | 12.54 (319) | 0.92 (24) | 9.45 (241) | 0.73 (19) | 4.00 (102) | 4.00 (102) | 23.0 (10.4) | |
| AF1 | ESV113N02TM_ ; ESV153N02TM_ ; ESV113N04TL_ ; ESV153N04TL_ ; ESV183N04TL_ ; ESV223N04TL_ ; ESV183N04TM_ ; ESV223N04TM_ ; ESV183N06TM_ ; ESV223N06TM_ ; | 9.42 (240) | 8.94 (228) | 18.5 (470) | 16.54 (420) | 0.92 (24) | 9.45 (241) | 0.73 (19) | 4.00 (102) | 4.00 (102) | 28.5 (12.9) | | |

_ = Last digit of part number: C = N4X Indoor (convection cooled)

~ = Last digit of part number: D = N4X Indoor (fan cooled)

| Conduit Hole Dimensions | | Type | N in (mm) | P in (mm) | Q in (mm) | S in (mm) | S1 in (mm) |
|-------------------------|--|------|--------------|--------------|--------------|--------------|---------------|
| | | AA1 | 3.14 (80) | 2.33 (59) | 1.50 (38) | .88 (22) | n/a |
| | | AA2 | 3.14 (80) | 4.18 (106) | 1.50 (38) | .88 (22) | n/a |
| | | AD1 | 3.56 (90) | 4.63 (118) | 1.50 (38) | .88 (22) | n/a |
| | | AB1 | 4.02 (102) | 5.00 (127) | 1.85 (47) | 1.06 (27) | n/a |
| | | AC1 | 4.48 (114) | 5.00 (127) | 1.85 (47) | 1.06 (27) | n/a |
| | | AE1 | 4.71 (120) | 5.70 (145) | 2.00 (51) | 1.375 (35) | 1.125 (28) |
| | | AF1 | 4.71 (120) | 5.70 (145) | 2.00 (51) | 1.375 (35) | 1.125 (28) |



3.2 Electrical Installation

Installation After a Long Period of Storage



STOP!

Severe damage to the drive can result if it is operated after a long period of storage or inactivity without reforming the DC bus capacitors.

If input power has not been applied to the drive for a period of time exceeding three years (due to storage, etc), the electrolytic DC bus capacitors within the drive can change internally, resulting in excessive leakage current. This can result in premature failure of the capacitors if the drive is operated after such a long period of inactivity or storage.

In order to reform the capacitors and prepare the drive for operation after a long period of inactivity, apply input power to the drive for 8 hours prior to actually operating the motor.

3.2.1 Power Connections



STOP!

If the kVA rating of the AC supply transformer is greater than 10 times the input kVA rating of the drive(s), an isolation transformer or 2-3% input line reactor must be added to the line side of the drive(s).



DANGER! Hazard of electrical shock!

Circuit potentials up to 600 VAC are possible. Capacitors retain charge after power is removed. Disconnect power and wait at least three minutes before servicing the drive.




STOP!

- Verify mains voltage before connecting to drive.
- Do not connect mains power to the output terminals (U,V,W)! Severe damage to the drive will result.
- Do not cycle mains power more than once every two minutes. Damage to the drive may result.

| Mains and Motor Terminations | | | |
|--|--------------------------|---------------|--|
| Type | Torque | Strip Length | |
| <5HP | 12 lb-in (1.3 Nm) | 0.25 in (6mm) | |
| ESV552xx2T, ESV752xx2T, ESV113xx4/6, ESV153xx4/6, ESV183xx6, ESV223xx6 | 16 lb-in (1.8 Nm) | 0.25 in (6mm) | |
| ESV552xx4Txx, ESV752xx4Txx, ESV552xx6Txx, ESV752xx6Txx | 12 lb-in (1.3Nm) | 0.25 in (6mm) | |
| ESV113xx2xxx, ESV153xx2xxx, ESV183xx4xxx, ESV223xx4xxx | 24 lb-in (2.7 Nm) | 0.25 in (6mm) | |
| Torque: N4X/IP65 Door Screws | | | |
| N4X/IP65 | 6-7 lb-in (0.67-0.79 Nm) | 0.25 in (6mm) | |


3.2.1.1 Mains Connection to 120VAC Single-Phase Supply






Installation


3.2.1.2 Mains Connection to 240VAC Single-Phase Supply



3.2.1.3 Mains Connection to Three-Phase Supply



3.2.1.4 Motor Connection



WARNING!

If the cable connection between the drive and the motor has an in-line contactor or circuit breaker then the drive must be stopped prior to opening/closing the contacts. Failure to do so may result in Overcurrent trips and/or damage to the inverter.



WARNING!

Leakage current may exceed 3.5 mA AC. The minimum size of the protective earth (PE) conductor shall comply with local safety regulations for high leakage current equipment.



STOP!

In the case of a Spinning Motor:

To bring free-wheeling loads such as fans to a rest before starting the drive, use the DC injection braking function. Starting a drive into a freewheeling motor creates a direct short-circuit and may result in damage to the drive.

Confirm motor suitability for use with DC injection braking.




3.2.1.5 Installation Recommendations for EMC Compliance

For compliance with EN 61800-3 or other EMC standards, motor cables, line cables and control or communications cables must be shielded with each shield/screen clamped to the drive chassis. This clamp is typically located at the conduit mounting plate.

The EMC requirements apply to the final installation in its entirety, not to the individual components used. Because every installation is different, the recommended installation should follow these guidelines as a minimum. Additional equipment (such as ferrite core absorbers on power conductors) or alternative practices may be required to meet conformance in some installations.


Motor cable should be low capacitance (core/core <75pF/m, core/shield <150pF/m). Filtered drives can meet the class A limits of EN 55011 and EN 61800-3 Category 2 with this type of motor cable up to 10 meters.

NOTE: Refer to Appendix A for recommended cable lengths. Any external line filter should have its chassis connected to the drive chassis by mounting hardware or with the shortest possible wire or braid.



3.2.1.6 NEMA 4X (IP65) Input Terminal Block

For NEMA 4X (IP65) models with integrated EMC filter and/or integrated line disconnect, the input terminal block is located on the right-hand side of the SMV inverter in the NEMA 4 X (IP65) enclosure. The single and three phase models are illustrated herein. Refer to paragraph 3.2.3 Control Terminals for pin out information.



WARNING

Power remains present for up to 3 minutes on power input terminals (L1, L2 and L3) and output terminals (U, V and W) even when the disconnect switch is in the OFF position. Remove input power ahead of the drive and wait 3 minutes before removing the terminal cover.



Installation

3.2.2 Fuses/Cable Cross-Sections



NOTE: Observe local regulations. Local codes may supersede these recommendations

| Type | | Recommendations | | | | |
|-----------------------------|---|---|--|--|-------------------------------------|-------|
| | | Fuse | Miniature circuit breaker ⁽¹⁾ | Fuse ⁽²⁾ or Breaker ⁽³⁾ (N. America) | Input Power Wiring (L1, L2, L3, PE) | |
| | | | | | [mm ²] | [AWG] |
| 120V 1~ (1/N/PE) | ESV251N01SXB | M10 A | C10 A | 10 A | 1.5 | 14 |
| | ESV371N01SXB, ESV371N01SX* | M16 A | C16 A | 15 A | 2.5 | 14 |
| | ESV751N01SXB, ESV751N01SX* | M25 A | C25 A | 25 A | 4 | 10 |
| | ESV112N01SXB, ESV112N01SX* | M32 A | C32 A | 30A | 4 | 10 |
| 240V 1~ (2/PE) | ESV251N01SXB, ESV251N02SXB, ESV371N01SXB, ESV371N02YXB, ESV371N02SF* | M10 A | C10 A | 10 A | 1.5 | 14 |
| | ESV751N01SXB, ESV751N02YXB, ESV751N02SF* | M16 A | C16 A | 15 A | 2.5 | 14 |
| | ESV112N02YXB, ESV112N02SFC, ESV112N01SXB ESV112N01SX* | M20 A | C20 A | 20 A | 2.5 | 12 |
| | ESV152N02YXB, ESV152N02SF* | M25 A | C25 A | 25 A | 2.5 | 12 |
| 240V 3~ (3/PE) | ESV222N02YXB, ESV222N02SF* | M32 A | C32A | 30 A | 4 | 10 |
| | ESV371N02YXB, ESV751N02YXB, ESV371N02Y_* ESV751N02Y_* | M10 A | C10 A | 10 A | 1.5 | 14 |
| | ESV112N02YXB, ESV152N02YXB, ESV112N02TXB, ESV152N02TXB, ESV112N02Y_* ESV152N02Y_* | M16 A | C16 A | 12 A | 1.5 | 14 |
| | ESV222N02YXB, ESV222N02TXB, ESV222N02YX* | M20 A | C20 A | 20 A | 2.5 | 12 |
| | ESV402N02TXB, ESV402N02T_* | M32 A | C32 A | 30 A | 4.0 | 10 |
| | ESV552N02TXB, ESV552N02T_~ | M40 A | C40 A | 35 A | 6.0 | 8 |
| | ESV752N02TXB, ESV752N02T_~ | M50 A | C50 A | 45 A | 10 | 8 |
| | ESV113N02TXB, ESV113N02TX_~ ESV113N02TM_~ | M80 A | C80 A | 80 A | 16 | 6 |
| | ESV153N02TXB, ESV153N02TX_~ ESV153N02TM_~ | M100 A | C100 A | 90 A | 16 | 4 |
| | 400V or 480V 3~(3/PE) | ESV371N04TXB...ESV222N04TXB ESV371N04T_*...ESV222N04T_* ESV371N04TF*...ESV222N04TF* | M10 A | C10 A | 10 A | 1.5 |
| ESV302N04T_* | | M16 A | C16 A | 15 A | 2.5 | 14 |
| ESV402N04TXB, ESV402N04T_* | | M16 A | C16 A | 20 A | 2.5 | 14 |
| ESV552N04TXB, ESV552N04T_* | | M20 A | C20 A | 20 A | 2.5 | 14 |
| ESV752N04TXB, ESV752N04T_~ | | M25 A | C25 A | 25 A | 4.0 | 10 |
| ESV113N04TXB, ESV113N04T_~ | | M40 A | C40 A | 40 A | 4 | 8 |
| ESV153N04TXB, ESV153N04T_~ | | M50 A | C50 A | 50 A | 10 | 8 |
| ESV183N04TXB, ESV183N04T_~ | | M63 A | C63A | 70 A | 10 | 6 |
| ESV223N04TXB, ESV223N04T_~ | | M80 A | C80 A | 80 A | 16 | 6 |
| ESV303N04TXB | | M100 A | C100 A | 100 A | 25 | 4 |
| 400V or 480V 3~(3/PE) | ESV373N04TXB | M125 A | C125 A | 125 A | 35 | 2 |
| | ESV453N04TXB | M160 A | C160 A | 150 A | 35 | 1 |
| | ESV751N06TXB...ESV222N06TXB ESV751N06T_*...ESV222N06T_* | M10 A | C10 A | 10 A | 1.5 | 14 |
| | ESV402N06TXB, ESV402N06T_* | M16 A | C16 A | 12 A | 1.5 | 14 |
| | ESV552N06TXB, ESV552N06T_* | M16 A | C16 A | 15 A | 2.5 | 14 |
| | ESV752N06TXB, ESV752N06T_~ | M20 A | C20 A | 20 A | 2.5 | 12 |
| | ESV113N06TXB, ESV113N06TX_~ ESV113N06TM_~ | M32 A | C32 A | 30 A | 4 | 10 |
| | ESV153N06TXB, ESV153N06TX_~ ESV153N06TM_~ | M40 A | C40 A | 40 A | 4 | 8 |
| | ESV183N06TXB, ESV183N06TX_~ ESV183N06TM_~ | M50 A | C50 A | 50 A | 6 | 8 |
| | ESV223N06TXB, ESV223N06TX_~ ESV223N06TM_~ | M63 A | C63 A | 60 A | 10 | 8 |
| 600V 3~(3/PE) | ESV303N06TXB | M80 A | C80 A | 70 A | 16 | 6 |
| | ESV373N06TXB | M100 A | C100 A | 90 A | 16 | 4 |
| | ESV453N06TXB | M125 A | C125 A | 110 A | 25 | 2 |



Notes for Fuse and Cable Table:

- (1) Installations with high fault current due to large supply mains may require a type D circuit breaker.
- (2) UL Class CC or T fast-acting current-limiting type fuses, 200,000 AIC, preferred. Bussman KTK-R, JJJ or JJS or equivalent.
- (3) Thermomagnetic type breakers preferred.


- ~ 11th digit of part number: F = Integral EMC Filter
 L = Integral EMC Filter and Integrated Disconnect Switch (NEMA 4X/IP65 Models only)
 M = Integrated Disconnect Switch (NEMA 4X/IP65 Models only)
 X = No EMC Filter/ No Disconnect Switch
 C = N4X Indoor only (convection cooled)
 E = N4X Indoor/Outdoor (convection cooled)
 D = N4X Indoor only (fan cooled)
 F = N4X Indoor/Outdoor (fan cooled)
- * = Last digit of part number:
 ~ = Last digit of part number:

Observe the following when using Ground Fault Circuit Interrupters (GFCIs):


- Installation of GFCI only between supplying mains and controller.
- The GFCI can be activated by:
 - capacitive leakage currents between the cable screens during operation (especially with long, screened motor cables)
 - connecting several controllers to the mains at the same time
 - RFI filters

3.2.3 Control Terminals

Control Terminal Strip for 0.33 - 10 HP (0.25 - 7.5 kW):



Control Terminal Strip for 15HP (11 kW) and Greater Drives:



NOTE

Control and communications terminals provide basic insulation when the drive is connected to a power system rated up to 300V between phase to ground (PE) and the applied voltage on terminals 16 and 17 is less than 250 VAC between phase to phase and ground (PE).



Installation

Control Terminal Strip Descriptions

| Terminal | Description | Important |
|----------|--|---|
| 1 | Digital Input: Start/Stop | input resistance = 4.3k Ω |
| 2 | Analog Common | |
| 5 | Analog Input: 0...10 VDC | input resistance: >50 k Ω |
| 6 | Internal DC supply for speed pot | +10 VDC, max. 10 mA |
| 25 | Analog Input: 4...20 mA | input resistance: 250 Ω |
| 4 | Digital Reference/Common | +15 VDC / 0 VDC, depending on assertion level |
| 11 | Internal DC supply for external devices | +12 VDC, max. 50 mA |
| 13A | Digital Input: Configurable with P121 | input resistance = 4.3k Ω |
| 13B | Digital Input: Configurable with P122 | |
| 13C | Digital Input: Configurable with P123 | |
| 13D* | Digital Input: Configurable with P124 | |
| 14 | Digital Output: Configurable with P142, P144 | DC 24 V / 50 mA; NPN |
| 30 | Analog Output: Configurable with P150...P155 | 0...10 VDC, max. 20 mA |
| 2* | Analog Common | |
| TXA* | RS485 TxA | |
| TXB* | RS485 TxB | |
| 16 | Relay output: Configurable with P140, P144 | AC 250 V / 3 A |
| 17 | | DC 24 V / 2 A ... 240 V / 0.22 A, non-inductive |

* = Terminal is part of the terminal strip for the 15-30HP (11-22 kW) Models only.

Assertion level of digital inputs

The digital inputs can be configured for active-high or active-low by setting the Assertion Level Switch (ALsw) and P120. If wiring to the drive inputs with dry contacts or with PNP solid state switches, set the switch and P120 to "High" (+). If using NPN devices for inputs, set both to "Low" (-). Active-high (+) is the default setting.

HIGH = +12 ... +30 V

LOW = 0 ... +3 V



NOTE

An **F_{RL}** fault will occur if the Assertion Level switch (ALsw) position does not match the parameter P120 setting and P100 or any of the digital inputs (P121...P124) is set to a value other than 0.



4 Commissioning













4.1 Local Keypad & Display

| SMV Models: 0.33-10HP (0.25-7.5kW) | SMV Models: 15HP (11kW) and greater |
|------------------------------------|-------------------------------------|
| | |
| 4-Character Display | 4-Character plus CTRL Display |

| Display | START BUTTON |
|---------|---|
| | In Local Mode (P100 = 0, 4, 6), this button will start the drive. |
| | STOP BUTTON |
| | Stops the drive, regardless of which mode the drive is in. WARNING! When JOG is active, the STOP button will not stop the drive! |
| | ROTATION |
| | In Local Mode (P100 = 0, 4, 6), this selects the motor rotation direction: <ul style="list-style-type: none"> - The LED for the present rotation direction (FWD or REV) will be on - Press R/F; the LED for the opposite rotation direction will blink - Press M within 4 seconds to confirm the change - The blinking direction LED will turn on, and the other LED will turn off When rotation direction is changed while the drive is running, the commanded direction LED will blink until the drive is controlling the motor in the selected direction. |
| | MODE |
| | Used to enter/exit the Parameter Menu when programming the drive and to enter a changed parameter value. |
| | UP AND DOWN BUTTONS |
| | Used for programming and can also be used as a reference for speed, PID setpoint, or torque setpoint. When the ▲ and ▼ buttons are the active reference, the middle LED on the left side of the display will be on. |



Commissioning

| | | | |
|--|--|---|--------------------------|
| Display | INDICATING LEDs (on 4-character display) | | |
|  | FWD LED: Indicate the present rotation direction is forward. Refer to ROTATION description above. | | |
|  | REV LED: Indicate the present rotation direction is reverse. Refer to ROTATION description above. | | |
|  | AUTO LED: Indicates that the drive has been put into Auto mode from one of the TB13 inputs (P121...P124 set to 1...7). Also indicates that PID mode is active (if enabled). | | |
|  | RUN LED: Indicates that the drive is running. | | |
|  | ▲ ▼ LED: Indicates that the ▲ ▼ are the active reference. | | |
|  | NOTE If the keypad is selected as the auto reference (P121...P124 is 6) and the corresponding TB-13 input is closed, the AUTO LED and ▲ ▼ LEDs will both be on. | | |
| FUNCTIONS THAT FOLLOW ARE APPLICABLE TO SMV DRIVES 15HP (11kW) AND GREATER | | | |
|  | CTRL The CTRL pushbutton selects the start and speed reference control sources for the drive. Press  mode button to accept the new control mode selection. | | |
| CTRL LEDs | | START CONTROL | REFERENCE CONTROL |
|  | [LOCAL] [MAN] | Keypad | P101 Settings |
|  | [LOCAL] [AUTO] | Keypad | Terminal 13x Settings |
|  | [REMOTE] [MAN] | Terminal Strip | P101 Settings |
|  | [REMOTE] [AUTO] | Terminal Strip | Terminal 13x Settings |
| If P100 = 6 the CTRL button is used to toggle start control between the terminal strip [REMOTE] and the keypad [LOCAL] | | - REM/LOC LED indicating the present start control source is ON - Press [CTRL]; the LED for other start control source will blink - Press [M] within 4 sec to confirm the change - Blinking LED will turn ON (the other LED will turn OFF) | |
| If P113 = 1 the CTRL button is used to toggle reference control between the TB-13x setup [AUTO] and P101 [MANUAL] | | - AUT/MAN LED indicating present reference control is ON - Press [CTRL]; the other reference control will blink - Press [M] within 4 sec to confirm change - Blinking LED will turn ON (the other LED will turn OFF) | |
| If P100 = 6 and P113 = 1, it is possible to change the start and reference control sources at the same time | | | |



| Display | START CONTROL | | |
|---------|--|--|--|
| | The REMOTE/LOCAL LEDs indicate the current start control source. If the start control source is a remote keypad or the network, then both LEDs will be OFF. | | |
| | REFERENCE CONTROL | | |
| | The AUTO/MANUAL LEDs indicate the current reference control source. | | |
| | IF P113 = 0 or 2, the AUTO/MANUAL LEDs will match the AUTO LED on the 4-character display. IF P113 = 0 and no AUTO reference has been setup on the terminal strip, the MANUAL LED will turn ON and the AUTO LED will turn OFF. | | |
| | IF P113 = 1, the AUTO/MANUAL LEDs show the commanded reference control source as selected by the [CTRL] button. If the [CTRL] button is used to set the reference control source to AUTO but no AUTO reference has been setup on the terminal strip, reference control will follow P101 but the AUTO LED will remain ON. | | |
| | UNITS LEDs | | |
| | HZ: current display value is in Hz | In Speed mode, if P178 = 0 then HZ LED will be ON. If P178 > 0, the Units LEDs follow the setting of P177 when the drive is in run (non-programming) mode. In Torque mode, the HZ LED will be ON when the drive is in run (non-programming) mode. | |
| | %: current display value is in % | | |
| | RPM: current display value is in RPM | | |
| | AMPS: current display value is in Amps | | |
| | /UNITS current display value is a per unit (i.e./sec, /min, /hr, etc.) | | In Pid mode, the Units LEDs follow the setting of P203 when the drive is in run (non-programming) mode. If P179 > 0, the Units LEDs will show the unit of the diagnostic parameter that is being displayed. |

4.2 Drive Display and Modes of Operation

Speed Mode Display

In the standard mode of operation, the drive frequency output is set directly by the selected reference (keypad, analog reference, etc.). In this mode, the drive display will show the drive's output frequency.

PID Mode Display

When the PID mode is enabled and active, the normal run display shows the actual PID setpoint. When PID mode is not active, the display returns to showing the drive's output frequency.


Torque Mode Display

When the drive is operating in Vector Torque mode, the normal run display shows the drive's output frequency.



Commissioning

4.3 Parameter Setting




4.4 Electronic Programming Module (EPM)

The EPM contains the drives operational memory. Parameter settings are stored in the EPM and setting changes are made to the "User settings" in the EPM.

An optional EPM Programmer (model EEPM1RA) is available that allows:

- An EPM to be copied directly to another EPM.
- An EPM to be copied to the memory of the EPM Programmer.
- Stored files can be modified in the EPM Programmer.
- Stored files can be copied to another EPM.



EPM Module
in SMV Drive

As the EPM Programmer is battery operated, parameter settings can be copied to an EPM and inserted into a drive without power being applied to the drive. This means that the drive will be fully operational with the new settings on the next application of power.

Additionally, when the drives parameter settings are burned into an EPM with the EPM Programmer, the settings are saved in two distinct locations; the "User settings" and the "OEM default settings". While the User settings can be modified in the drive, the OEM settings cannot. Thus, the drive can be reset not only to the "factory" drive default settings (shown in this manual), but can be set to the Original Machine settings as programmed by the OEM.

While the EPM can be removed for copying or to use in another drive, it must be installed for the drive to operate (a missing EPM will trigger an **F_F I** fault)



4.5 Parameter Menu

4.5.1 Basic Setup Parameters

| Code | | Possible Settings | | IMPORTANT |
|-------|---------------------------|-------------------|--|--|
| No. | Name | Default | Selection | |
| P 100 | Start Control Source | 0 | 0 Local Keypad | Use RUN button on front of drive to start |
| | | | 1 Terminal Strip | Use start/stop circuit wired into the terminal strip. Refer to section 3.2.3 |
| | | | 2 Remote Keypad Only | Use RUN button on optional Remote Keypad to start |
| | | | 3 Network Only | <ul style="list-style-type: none"> Start command must come from network (Modbus, CANopen, etc) Requires optional communication module (refer to the network module documentation). Must also set one of the TB-13 inputs to 9 (Network Enable); see P121...P124 |
| | | | 4 Terminal Strip or Local Keypad | Allows start control to be switched between terminal strip and local keypad using one of the TB-13 inputs. See note below. |
| | | | 5 Terminal Strip or Remote Keypad | Allows start control to be switched between terminal strip and optional remote keypad using one of the TB-13 inputs. See Note below |
| | | | 6 CTRL button select | Allows start control to be switched between terminal strip and local keypad using the CTRL button. NOTE: P100 Selection 6 is applicable to SMV 15HP (11kW) and greater models only. |
| | | | WARNING! P100 = 0 disables TB-1 as a STOP input! STOP circuitry may be disabled if parameters are reset back to defaults (see P199) | |
| | | | NOTE <ul style="list-style-type: none"> P100 = 4, 5: To switch between control sources, one of the TB-13 inputs (P121...P124) must be set to 08 (Control Select); TB-13x OPEN (or not configured): Terminal strip control TB-13x CLOSED: Local (P100 = 4) or Remote (P100 = 5) keypad P100 = 0, 1, 4, 6: Network can take control if P121...P124 = 9 and the corresponding TB-13x input is CLOSED. The STOP button on the front of the drive is always active except in JOG mode. TB-1 is an active STOP input if P100 is set to a value other than 0. An F_{RL} fault will occur if the Assertion Level switch (ALsw) position does not match the P120 setting and P100 is set to a value other than 0. | |
| P 101 | Standard Reference Source | 0 | 0 Keypad (Local or Remote) | Selects the default speed or torque reference when no Auto Reference is selected using the TB-13 inputs. |
| | | | 1 0-10 VDC | |
| | | | 2 4-20 mA | |
| | | | 3 Preset #1 | |
| | | | 4 Preset #2 | |
| | | | 5 Preset #3 | |
| | | | 6 Network | |



Commissioning

| Code | | Possible Settings | | | | IMPORTANT |
|---|-------------------------|---|---|------------------------------|--|--|
| No. | Name | Default | Selection | | | |
| P 102 | Minimum Frequency | 0.0 | 0.0 | {Hz} | P103 | <ul style="list-style-type: none"> P102, P103 are active for all speed references When using an analog speed reference, also see P160, P161 |
| P 103 | Maximum Frequency | 60.0 | 7.5 | {Hz} | 500 | |
| | | NOTE <ul style="list-style-type: none"> P103 cannot be set below Minimum Frequency (P102) To set P103 above 120 Hz: <ul style="list-style-type: none"> Scroll up to 120 Hz; display shows H iFr (flashing). Release ▲ button and wait one second. Press ▲ button again to continue increasing P103. | | | | |
| WARNING! Consult motor/machine manufacturer before operating above rated frequency. Overspeeding the motor/machine may cause damage to equipment and injury to personnel! | | | | | | |
| P 104 | Acceleration Time 1 | 20.0 | 0.0 | {s} | 3600 | <ul style="list-style-type: none"> P104 = time of frequency change from 0 Hz to P167 (base frequency) P105 = time of frequency change from P167 to 0 Hz For S-ramp accel/decel, adjust P106 |
| P 105 | Deceleration Time 1 | 20.0 | 0.0 | {s} | 3600 | |
| EXAMPLE: IF P103 = 120 Hz, P104 = 20.0 s and P167 (base frequency) = 60 Hz; then the rate of frequency change from 0 Hz to 120 Hz = 40.0 s | | | | | | |
| P 106 | S-Ramp Integration Time | 0.0 | 0.0 | {s} | 50.0 | <ul style="list-style-type: none"> P106 = 0.0: Linear accel/decel ramp P106 > 0.0: Adjusts S-ramp curve for smoother ramp |
| P 107 ⁽¹⁾ | Line Voltage Selection | 1* | 0 | Low (120, 200, 400, 480VAC) | * The default setting is 1 for all drives except when using "reset 50" (Parameter P199, selection 4) with 480V models. In this case, the default setting is 0. | |
| | | | 1 | High (120, 240, 480, 600VAC) | | |
| P 108 | Motor Overload | 100 | 30 | {%} | 100 | P108 = $\frac{\text{motor current rating}}{\text{SMV output rating}} \times 100$ Example: if motor = 3amps and SMV = 4amps, then P108 = 75% |
| | | | NOTE Do not set above rated motor current as listed on the motor dataplate. The motor thermal overload function of the SMV is UL approved as a motor protection device. If the line power is cycled, the motor thermal state is reset to cold state. Cycling power after an overload fault could result in significantly reducing the motor life. | | | |
| P 109 | Motor Overload Type | 0 | 0 | Speed Compensation | | |
| | | | 1 | No Speed Compensation | | |


(1) Any changes to this parameter will not take effect until the drive is stopped



| Code | | Possible Settings | | IMPORTANT |
|---|--------------|--|------------------------------|---|
| No. | Name | Default | Selection | |
| P110 | Start Method | 0 | 0 Normal | <p>Drive will automatically start when power is applied.</p> <p>When start command is applied, drive will apply DC braking according to P174, P175 prior to starting the motor</p> <p>Drive will automatically restart after faults, or when power is applied.</p> <p>Combines settings 2 and 3</p> <ul style="list-style-type: none"> • Drive will automatically restart after faults, or when power is applied. • After 3 failed attempts, drive will Auto Restart with DC brake. • P110 = 5: Performs speed search, starting at Max Frequency (P103) • P110 = 6: Performs speed search, starting at the last output frequency prior to faulting or power loss • If P111 = 0, a flying START is performed when a start command is applied. |
| | | | 1 Start on Power-up | |
| | | | 2 Start with DC Brake | |
| | | | 3 Auto Restart | |
| | | | 4 Auto Restart with DC Brake | |
| | | | 5 Flying Start/Restart #1 | |
| | | | 6 Flying Start/Restart #2 | |
| | | NOTE <ul style="list-style-type: none"> • P110 = 0, 2: Start command must be applied at least 2 seconds after power-up; F_{UF} fault will occur if start command is applied too soon. • P110 = 1, 3...6: For automatic start/restart, the start source must be the terminal strip and the start command must be present. • P110 = 2, 4...6: If P175=999.9, dc braking will be applied for 15s. • P110 = 3...6: Drive will attempt 5 restarts; if all restart attempts fail, drive displays LC (fault lockout) and requires manual reset. • P110 = 5, 6: If drive cannot catch the spinning motor, drive will trip into F_{rF} fault. | | |
| WARNING! Automatic starting/restarting may cause damage to equipment and/or injury to personnel! Automatic starting/restarting should only be used on equipment that is inaccessible to personnel. | | | | |
| P111 | Stop Method | 0 | 0 Coast | <p>Drive's output will shut off immediately upon a stop command, allowing the motor to coast to a stop</p> <p>The drive's output will shut off and then the DC Brake will activate (refer to P174, P175)</p> <p>The drive will ramp the motor to a stop according to P105 or P126.</p> <p>The drive will ramp the motor to 0 Hz and then the DC Brake will activate (refer to P174, P175)</p> |
| | | | 1 Coast with DC Brake | |
| | | | 2 Ramp | |
| | | | 3 Ramp with DC Brake | |
| P112 | Rotation | 0 | 0 Forward Only | If PID mode is enabled, reverse direction is disabled (except for Jog). |
| | | | 1 Forward and Reverse | |



Commissioning

| Code | | Possible Settings | | IMPORTANT |
|------|---------------------|---|--|---|
| No. | Name | Default | Selection | |
| P113 | Auto/Manual Control | 0 | 0 Terminal Strip Control | The reference is dictated by the settings and state of the TB-13x terminals. If no AUTO reference has been setup on the terminal strip then reference control is dictated by P101. |
| | | | 1 Auto/Manual (CTRL button select) | Allows the reference to be switched between auto and manual using the CTRL pushbutton on the drive keypad. If the CTRL pushbutton has selected AUTO reference but no AUTO reference has been setup on the terminal strip, then reference control is dictated by P101. |
| | | | 2 Manual Control Only | Reference is dictated by P101 regardless of any AUTO source that may be selected by the TB-13x terminals. |
| | |  NOTE | P113 is applicable to SMV 15HP (11kW) and greater models only. | |



4.5.2 I/O Setup Parameters

| Code | | Possible Settings | | IMPORTANT |
|--------------------------------|--|-------------------|----------------------------|--|
| No. | Name | Default | Selection | |
| P 120 | Assertion Level | 2 | 1 Low 2 High | P120 and the Assertion Level switch must both match the desired assertion level unless P100, P121...P124 are all set to 0. Otherwise an F.AL fault will occur. |
| P 121 | TB-13A Input Function | 0 | 0 None | Disables input |
| P 122 | TB-13B Input Function | | 1 AUTO Reference: 0-10 VDC | For frequency mode, see P160...P161, For PID mode, see P204...P205, For vector torque mode, see P330 |
| | | | 2 AUTO Reference: 4-20 mA | For frequency mode see P131...P137, For PID mode, see P231...P233, For torque mode see, P331...P333 |
| P 123 | TB-13C Input Function | | * 13D: 3 = Reserved | <ul style="list-style-type: none"> Normally open: Close input to increase or decrease speed, PID or torque setpoint. MOP Up is not active while in STOP |
| P 124 | TB-13D* Input Function | | 4 AUTO Reference: MOP Up | |
| | | | 5 AUTO Reference: MOP Down | |
| | | | 6 AUTO Reference: Keypad | |
| | | | 7 AUTO Reference: Network | |
| | | | 8 Control Select | Use when P100 = 4, 5 to switch between terminal strip control and local or remote keypad control. Required to start the drive through the network. Open = Forward Closed = Reverse |
| | | | 9 Network Enable | |
| | | | 10 Reverse Rotation | |
| | | | 11 Start Forward | |
| | | | 12 Start Reverse | Refer to Note for typical circuit |
| | | | 13 Run Forward | Refer to Note for typical circuit |
| 14 Run Reverse | | | | |
| 15 Jog Forward | Jog Forward speed = P134 | | | |
| 16 Jog Reverse | Jog Reverse speed = P135 Active even if P112 = 0 | | | |
| 17 Accel/Decel #2 | Refer to P125, P126 | | | |
| 18 DC Brake | Refer to P174; close input to override P175 | | | |
| 19 Auxiliary Ramp to Stop | Normally closed: Opening input will ramp drive to STOP according to P127, even if P111 is set to Coast (0 or 1). | | | |
| 20 Clear Fault | Close to reset fault | | | |
| 21 External Fault F_EF | Normally closed circuit; open to trip | | | |
| 22 Inverse External Fault F_EF | Normally open circuit; close to trip | | | |
| | WARNING! Jog overrides all STOP commands! To stop the drive while in Jog mode, the Jog input must be deactivated or a fault condition induced. | | | |



Commissioning

| Code | | Possible Settings | | | IMPORTANT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|---|---|------|-----------|------|---|--------------|-----|-----|-----|---|---|----|----|---|----|---|----|---|----|----|---|---|---|---|----|---|---|----|---|---|----|---|---|---|---|---|---|
| No. | Name | Default | Selection | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>NOTE</p> <ul style="list-style-type: none"> When input is activated, settings 1...7 override P101 When TB-13A...TB-13D are configured for Auto References other than MOP, TB-13D overrides TB-13C, TB-13C overrides TB-13B and TB-13B overrides TB-13A. Any other Auto Reference will have priority over MOP. Settings 10...14 are only valid in Terminal Strip mode (P100 = 1, 4, 5, 6) If Start/Run/Jog Forward and Start/Run/Jog Reverse are both activated, drive will STOP If Jog input is activated while the drive is running, the drive will enter Jog mode; when Jog input is deactivated, drive will STOP An F..RL fault will occur if the Assertion Level switch (ALsw) position does not match the P120 setting and any of the digital inputs (P121...P124) are set to a value other than 0. An F..I L fault will occur under the following conditions: <ul style="list-style-type: none"> TB-13A...TB-13D settings are duplicated (each setting, except 0 and 3, can only be used once) One input is set to "MOP Up" and another is not set to "MOP Down", or vice-versa. One input is set to 10 and another input is set to 11...14. One input is set to 11 or 12 and another input is set for 13 or 14. Typical control circuits are shown below: <ul style="list-style-type: none"> If any input is set to 10, 12 or 14, P112 must be set to 1 for Reverse action to function. | <p>Run / Stop with Direction P121 = 10</p> | <p>Start Forward / Start Reverse P121 = 11, P122 = 12</p> | <p>Run Forward / Run Reverse P121 = 13, P122 = 14</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | P 125 | Acceleration Time 2 | 20.0 | 0.0 | {s} | 3600 | <ul style="list-style-type: none"> Selected using TB-13A...TB-13D (P121...P124 = 17) For S-ramp accel/dec, adjust P106 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | P 126 | Deceleration Time 2 | 20.0 | 0.0 | {s} | 3600 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | P 127 | Deceleration Time for Auxiliary Ramp to Stop | 20.0 | 0.0 | {s} | 3600 | <ul style="list-style-type: none"> Selected using TB-13A...TB-13D (P121...P124 = 19). For S-ramp accel/dec, adjust P106 Once executed, this ramp time has priority over P105 and P126. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | P 131 | Preset Speed #1 | 0.0 | 0.0 | {Hz} | 500 | <table border="1"> <thead> <tr> <th>PRESET SPEED</th> <th>13A</th> <th>13B</th> <th>13C</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>X</td> <td>--</td> <td>--</td> </tr> <tr> <td>2</td> <td>--</td> <td>X</td> <td>--</td> </tr> <tr> <td>3</td> <td>--</td> <td>--</td> <td>X</td> </tr> <tr> <td>4</td> <td>X</td> <td>X</td> <td>--</td> </tr> <tr> <td>5</td> <td>X</td> <td>--</td> <td>X</td> </tr> <tr> <td>6</td> <td>--</td> <td>X</td> <td>X</td> </tr> <tr> <td>7</td> <td>X</td> <td>X</td> <td>X</td> </tr> </tbody> </table> | PRESET SPEED | 13A | 13B | 13C | 1 | X | -- | -- | 2 | -- | X | -- | 3 | -- | -- | X | 4 | X | X | -- | 5 | X | -- | X | 6 | -- | X | X | 7 | X | X | X |
| | PRESET SPEED | 13A | 13B | 13C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1 | X | -- | -- | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | -- | X | -- | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3 | -- | -- | X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 4 | X | X | -- | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | X | -- | X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | -- | X | X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | X | X | X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P 132 | Preset Speed #2 | 0.0 | 0.0 | {Hz} | 500 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P 133 | Preset Speed #3 | 0.0 | 0.0 | {Hz} | 500 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P 134 | Preset Speed #4 | 0.0 | 0.0 | {Hz} | 500 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P 135 | Preset Speed #5 | 0.0 | 0.0 | {Hz} | 500 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P 136 | Preset Speed #6 | 0.0 | 0.0 | {Hz} | 500 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P 137 | Preset Speed #7 | 0.0 | 0.0 | {Hz} | 500 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |



| Code | | Possible Settings | | IMPORTANT |
|----------------------|---|-------------------|---|--|
| No. | Name | Default | Selection | |
| P 140 | Relay Output TB-16, 17 | 0 | 0 None | Disables the output |
| | | | 1 Run | Energizes when the drive is running |
| | | | 2 Reverse | Energizes when reverse rotation is active |
| | | | 3 Fault | De-energizes when the drive trips, or power is removed |
| | | | 4 Inverse Fault | Energizes when the drive trips |
| | | | 5 Fault Lockout | P110 = 3...6: De-energizes if all restart attempts fail |
| | | | 6 At Speed | Energizes when output frequency = commanded frequency |
| | | | 7 Above Preset Speed #6 | Energizes when output frequency > P136 |
| | | | 8 Current Limit | Energizes when motor current = P171 |
| | | | 9 Follower Loss (4-20 mA) | Energizes when 4-20 mA signal falls below 2 mA |
| | | | 10 Loss of Load | Energizes when motor load drops below P145; Refer to P146 also |
| | | | 11 Local Keypad Control Active | |
| | | | 12 Terminal Strip Control Active | Energizes when the selected source is active for start control |
| | | | 13 Remote Keypad Control Active | |
| | | | 14 Network Control Active | |
| | | | 15 Standard Reference Active | Energizes when P101 reference is active |
| | | | 16 Auto Reference Active | Energizes when Auto Reference is activated using TB-13 input; refer to P121...P124 |
| | | | 17 Sleep Mode Active | Refer to P240...P242 |
| | | | 18 PID Feedback < Min. Alarm | Energizes when PID feedback signal < P214 |
| | | | 19 Inverse PID Feedback < Min. Alarm | De-energizes when PID feedback signal < P214 |
| | | | 20 PID Feedback > Max Alarm | Energizes when PID feedback signal > P215 |
| | | | 21 Inverse PID Feedback > Max Alarm | De-energizes when PID feedback signal > P215 |
| | | | 22 PID Feedback within Min/Max Alarm range | Energizes when PID feedback signal is within the Min/Max Alarm range; refer to P214, P215 |
| | | | 23 PID Feedback outside Min/Max Alarm range | Energizes when PID feedback signal is outside the Min/Max Alarm range; refer to P214, P215 |
| | | | 24 Reserved | |
| 25 Network Activated | Requires optional communication module (refer to the network module documentation). | | | |
| P 142 | TB-14 Output | 0 | 0...23 (same as P140) | |
| | | | 24 Dynamic Braking | For use with Dynamic Braking option |
| | | | 25 Network Activated | Requires optional communication module (refer to the network module documentation). |



Commissioning

| Code | | Possible Settings | | | | IMPORTANT | | | | | | | | | | | | | | | | | |
|-------|---|-------------------|--|---------------------------|-------------|--|---|-------------|---|----|----|---|----|-----|---|-----|----|---|-----|-----|---|--|--|
| No. | Name | Default | Selection | | | | | | | | | | | | | | | | | | | | |
| P 144 | Digital Output Inversion | | <table border="1"> <tr> <td>P144</td> <td>Invert P142</td> <td>Invert P140</td> </tr> <tr> <td>0</td> <td>NO</td> <td>NO</td> </tr> <tr> <td>1</td> <td>NO</td> <td>YES</td> </tr> <tr> <td>2</td> <td>YES</td> <td>NO</td> </tr> <tr> <td>3</td> <td>YES</td> <td>YES</td> </tr> </table> | | | P144 | Invert P142 | Invert P140 | 0 | NO | NO | 1 | NO | YES | 2 | YES | NO | 3 | YES | YES | Used to invert the selections for P140 (Relay Output) and P142 (TB-14 Output). EXAMPLE: When P140 = 6 (AT SPEED), the relay is energized when output frequency = commanded frequency. If P144=1 or 3, then P140 is inverted (INVERSE AT SPEED) and the relay is energized when the output frequency does not equal the command frequency. | | |
| | | | P144 | Invert P142 | Invert P140 | | | | | | | | | | | | | | | | | | |
| | | | 0 | NO | NO | | | | | | | | | | | | | | | | | | |
| 1 | NO | YES | | | | | | | | | | | | | | | | | | | | | |
| 2 | YES | NO | | | | | | | | | | | | | | | | | | | | | |
| 3 | YES | YES | | | | | | | | | | | | | | | | | | | | | |
| | NOTE Inverting P140 or P142 when the parameter is set to NONE (0) will result in the output being energized continuously. | | | | | | | | | | | | | | | | | | | | | | |
| | NOTE For SMVector drives rated at 0.33 to 10 HP (0.25 to 7.5 kW), P144 is only available with software versions 3.0 and higher (refer to P501). | | | | | | | | | | | | | | | | | | | | | | |
| P 145 | Loss of Load Threshold | 0 | 0 | {%} | 200 | P140, P142 = 10: Output will energize if motor load falls below the P145 value longer than the P146 time | | | | | | | | | | | | | | | | | |
| P 146 | Loss of Load Delay | 0.0 | 0.0 | {s} | 240.0 | | | | | | | | | | | | | | | | | | |
| P 150 | TB-30 Output | 0 | 0 | None | | 2-10 VDC signal can be converted to 4-20 mA with a total circuit impedance of 500 Ω | | | | | | | | | | | | | | | | | |
| | | | 1 | 0-10 VDC Output Frequency | | | | | | | | | | | | | | | | | | | |
| | | | 2 | 2-10 VDC Output Frequency | | | | | | | | | | | | | | | | | | | |
| | | | 3 | 0-10 VDC Load | | | | | | | | | | | | | | | | | | | |
| | | | 4 | 2-10 VDC Load | | | | | | | | | | | | | | | | | | | |
| | | | 5 | 0-10 VDC Torque | | | | | | | | | | | | | | | | | | | |
| | | | 6 | 2-10 VDC Torque | | | | | | | | | | | | | | | | | | | |
| | | | 7 | 0-10 VDC Power (kW) | | | | | | | | | | | | | | | | | | | |
| | | | 8 | 2-10 VDC Power (kW) | | | | | | | | | | | | | | | | | | | |
| | | | 9 | Network Controlled | | | Requires optional communication module (refer to the network module documentation). | | | | | | | | | | | | | | | | |
| P 152 | TB-30 Scaling: Frequency | 60.0 | 3.0 | {Hz} | 2000 | If P150 = 1 or 2, sets the frequency at which output equals 10 VDC | | | | | | | | | | | | | | | | | |
| P 153 | TB-30 Scaling: Load | 200 | 10 | {%} | 500 | If P150 = 3 or 4, sets the Load (as a percent of drive current rating) at which output equals 10 VDC. | | | | | | | | | | | | | | | | | |
| P 154 | TB-30 Scaling: Torque | 100 | 10 | {%} | 1000 | If P150 = 5 or 6, sets the Torque (as a percent of motor rated torque) at which output equals 10 VDC | | | | | | | | | | | | | | | | | |
| P 155 | TB-30 Scaling: Power (kW) | 1.0 | 0.1 | {kW} | 200.0 | If P150 = 7 or 8, sets the power at which output equals 10 VDC | | | | | | | | | | | | | | | | | |

(1) Any changes to this parameter will not take effect until the drive is stopped



4.5.3 Advanced Setup Parameters

| Code | | Possible Settings | | | | IMPORTANT |
|----------------------|-------------------------|---|-----------|-----------|-------|--|
| No. | Name | Default | Selection | | | |
| P 160 | Speed at Minimum Signal | 0.0 | -999.0 | {Hz} | 1000 | |
| P 161 | Speed at Maximum Signal | 60.0 | -999.0 | {Hz} | 1000 | |
| | | <p>i NOTE</p> <ul style="list-style-type: none"> • P160 sets the output frequency at 0% analog input • P161 sets the output frequency at 100% analog input • P160 or P161 < 0.0 Hz: For scaling purposes only; does not indicate opposite direction! • P160 > P161: Drive will react inversely to analog input signal | | | | |
| P 162 | Analog Input Filter | 0.01 | 0.00 | {s} | 10.00 | Adjusts the filter on the analog inputs (TB-5 and TB-25) to reduce the effect of signal noise |
| P 163 | TB-25 Loss Action | 0 | 0 | No Action | | <ul style="list-style-type: none"> • Selects the reaction to a loss of the 4-20 mA signal at TB-25. • Signal is considered lost if it falls below 2 mA • Digital outputs can also indicate a loss of 4-20 mA signal; see P140, P142 |
| | | <ol style="list-style-type: none"> 1 Fault F_{oL} 2 Go to Preset when TB-25 is: Speed reference: P137 PID feedback source: P137 PID setpoint reference: P233 Torque reference: P333 | | | | |
| P 166 | Carrier Frequency | See Notes | 0 | 4 kHz | | <ul style="list-style-type: none"> • As carrier frequency is increased, motor noise is decreased • Observe derating in section 2.3 • Automatic shift to 4 kHz at 120% load • NEMA 4X (IP65) Models: Default = 0 (4kHz) • NEMA 1 (IP31) Models: Default = 1 (6kHz) |
| | | | 1 | 6 kHz | | |
| | | | 2 | 8 kHz | | |
| | | | 3 | 10 kHz | | |
| P 167 ⁽¹⁾ | Base Frequency | 60.0 | 25.0 | {Hz} | 1500 | |
| P 168 | Fixed Boost | | 0.0 | {%} | 30.0 | |
| | | <p>i NOTE</p> <ul style="list-style-type: none"> • P167 = rated motor frequency for standard applications • P168 = default setting depends on drive rating | | | | |
| P 169 | Accel Boost | 0.0 | 0.0 | {%} | 20.0 | Accel Boost is only active during acceleration |
| P 170 | Slip Compensation | 0.0 | 0.0 | {%} | 10.0 | Increase P170 until the motor speed no longer changes between no load and full load conditions. |

(1) Any changes to this parameter will not take effect until the drive is stopped



Commissioning

| Code | | Possible Settings | | | | IMPORTANT |
|-------|------------------------------|-------------------|---|--|--------|---|
| No. | Name | Default | Selection | | | |
| P 171 | Current Limit | Max I | 30 | {%} | Max I | <ul style="list-style-type: none"> When the limit is reached, the drive displays CL(Current Limit), and either the acceleration time increases or the output frequency decreases. Digital outputs can also indicate when the limit is reached; see P140, P142. Refer to section 2.3 for the maximum output current Max I (%) |
| P 172 | Current Limit Reduction | 0 | 0 | Current Limit Reduction Active - Normal response | - | In field weakening, the Current Limit is inversely proportional to the speed. |
| | | | 1 | Current Limit Reduction Active - Fast response | - | |
| | | | 2 | Current Limit Reduction Disabled - Normal response | - | |
| | | | 3 | Current Limit Reduction Disabled - Fast response | - | |
| P 174 | DC Brake Voltage | 0.0 | 0.0 | {%} | 30.0 | Setting is a percent of the nominal DC bus voltage. |
| P 175 | DC Brake Time | 0.0 | 0.0 | {s} | 999.9 | |
| | | | NOTE: CONFIRM MOTOR SUITABILITY FOR USE WITH DC BRAKING DC Brake voltage (P174) is applied for the time specified by P175 with the following exceptions: <ul style="list-style-type: none"> If P111=1, 3 and P175=999.9 the brake voltage will be applied continuously until a run or fault condition occurs. If P110=2, 4...6 and P175=999.9, brake voltage will be applied for 15s If P121...P124=18 and the corresponding TB-13 input is CLOSED, brake voltage will be applied until the TB-13 input is OPENED or a fault condition occurs. | | | |
| P 177 | Speed Units | 0 | 0 | Hz | | Select the UNITS LED that will be illuminated when the drive is running in speed control mode. For this parameter to be used, P178 must be set to a value other than 0. IF P178 is set to 0, the HZ LED will be illuminated regardless of the value set in P177. |
| | | | 1 | RPM | | |
| | | | 2 | % | | |
| | | | 3 | /UNITS | | |
| | | | 4 | NONE | | |
| P 178 | Display Frequency Multiplier | 0.00 | 0.00 | | 650.00 | <ul style="list-style-type: none"> Allows frequency display to be scaled P178 = 0.00: Scaling disabled P178 > 0.00: Display = Actual Frequency X P178 |
| | | | EXAMPLE If P178 = 29.17 and actual frequency = 60 Hz, then Drive displays 1750 (rpm) | | | |
| P 179 | Run Screen Display | 0 | 0 | {Parameter Number} | 599 | <ul style="list-style-type: none"> 0 = Normal Run Screen, this display depends on mode of operation. Refer to section 4.2. Other selections choose a diagnostic parameter to display (P501...P599). |
| P 180 | Oscillation Damping Control | 0 | 0 | | 80 | 0 = Damping disabled Compensation for resonances within drive |

(2) Parameter currently applicable to ALL SMV models rated at 15 Hp (11.0 kW) and higher

Commissioning



| Code | | Possible Settings | | | | IMPORTANT |
|-------|---|---|---|---|-------------------------------------|---|
| No. | Name | Default | Selection | | | |
| P 181 | Skip frequency 1 | 0.0 | 0.0 | {Hz} | 500 | <ul style="list-style-type: none"> Drive will not run in the defined skip range; used to skip over frequencies that cause mechanical vibration P181 and P182 define the start of the skip ranges P184 > 0 defines the bandwidth of both ranges. |
| P 182 | Skip frequency 2 | 0.0 | 0.0 | {Hz} | 500 | |
| P 184 | Skip frequency bandwidth | 0.0 | 0.0 | {Hz} | 10.0 | |
| | | NOTE Bandwidth (Hz) = f_s (Hz) + P184 (Hz) f_s = P181 or P182 EXAMPLE: P181 = 18 Hz and P184 = 4 Hz; skip range is from 18 to 22 Hz | | | | |
| P 189 | Integrated Dynamic Brake | | 0 Disabled 1 Enabled | | | |
| P 190 | Motor Braking | | 0 Disabled 1 Braking with BUS threshold 2 Braking always on with deceleration 3 Braking with bus regulator 4 Special (Consult factory before using) | | | |
| P 191 | Motor Brake Level | 0 | 0 | {%} | 75 (flux braking disabled) | Active when P190 > 0 and drive is in deceleration mode. Use to reduce deceleration time on high inertia loads. NOTE: Over usage of P190 can cause frequent 'overload' trips "F.PF" Not active for P300 = 5 (Torque mode) |
| P 192 | Motor Braking Deceleration Reduction Level | 0.0 | 0 | | P167 (base freq) | Active when P190 > 0 and P192 > 0.0. Drive is in deceleration mode. Use to reduce deceleration time on high inertia loads. NOTE: Usage of P192 can cause the drive to decelerate faster than settings in P105/P127. Not active for P300 = 5 (Torque mode) |
| P 194 | Password | 225 | 0000 | | 9999 | <ul style="list-style-type: none"> Must enter password to access parameters P194 = 0000: Disables password Default =0 for SMV models ≥ 15 Hp (11.0 kW) |
| P 197 | Clear Fault History | 0 | 0 No Action 1 Clear Fault History | | | |
| P 199 | Program Selection (continued on next page) | | 0 Operate from User settings 1 Operate from OEM settings 2 Reset to OEM default settings 3 Reset to 60 Hz default settings 4 Reset to 50 Hz default settings 5 Translate | Refer to Notes 1, 2 and 3 Refer to Note 1 <ul style="list-style-type: none"> Refer to Note 4 Parameters are reset to the defaults listed in this manual. For P199=4, the following exceptions apply: <ul style="list-style-type: none"> - P103, P152, P161, P167 = 50.0 Hz - P304 = 50 Hz; - P305 = 1450 RPM - P107 = 0 (480 V drives only) Refer to Note 5 | | |
| | | WARNING! Modification of P199 can affect drive functionality! STOP and EXTERNAL FAULT circuitry may be disabled! Check P100 and P121...P124 | | | | |

(2) Parameter currently applicable to ALL SMV models rated at 15 Hp (11.0 kW) and higher



Commissioning

| Code | | Possible Settings | | IMPORTANT |
|-------|---|-------------------|--|-----------|
| No. | Name | Default | Selection | |
| P 199 | Program Selection (continued from last page) | | <p>NOTE 1 If the EPM does not contain valid OEM settings, a flashing GF will be displayed when P199 is set to 1 or 2.</p> <p>NOTE 2 When P199 is set to 1, the drive operates from the OEM settings stored in the EPM Module and no other parameters can be changed (GE will be displayed if attempted).</p> <p>NOTE 3 Auto Calibration is not possible when operating from OEM Settings.</p> <p>NOTE 4 Reset 60 and Reset 50 will set the Assertion Level (P120) to "2" (High). P120 may need to be reset for the digital input devices being used. An F_RL fault may occur if P120 and the Assertion switch are not set identically.</p> <p>NOTE 5 If an EPM that contains data from a previous compatible software version is installed:</p> <ul style="list-style-type: none"> The drive will operate according to the previous data, but parameters cannot be changed (GE will be displayed if attempted) To update the EPM to the current software version, set P199 = 5. The parameters can now be changed but the EPM is incompatible with previous software revisions. | |


4.5.4 PID Parameters

| Code | | Possible Settings | | IMPORTANT |
|------|---------------------|-------------------|---|--|
| No. | Name | Default | Selection | |
| P200 | PID Mode | 0 | 0 Disabled 1 Normal-acting 2 Reverse-acting | <ul style="list-style-type: none"> Normal-acting: As feedback increases, motor speed decreases Reverse-acting: As feedback increases, motor speed increases PID mode is disabled in Vector Torque mode (P300 = 5) |
| | | | <p>NOTE To activate PID mode, one of the TB-13 inputs (P121...P124) must be used to select the Auto Reference that matches the desired PID setpoint reference. If the selected PID setpoint reference uses the same analog signal as the PID feedback (P201), an F_I L fault will occur. Example: The desired PID setpoint reference is the keypad (▲ and ▼). Set TB-13x = 6 (Auto Reference: Keypad):</p> <ul style="list-style-type: none"> TB-13x = closed: PID mode is active TB-13x = open: PID mode is disabled and the drive speed will be controlled by the reference selected in P101. | |
| P201 | PID Feedback Source | 0 | 0 4-20 mA (TB-25) 1 0-10 VDC (TB-5) | Must be set to match the PID feedback signal |
| P202 | PID Decimal Point | 1 | 0 PID Display = XXXX 1 PID Display = XXX.X 2 PID Display = XX.XX 3 PID Display = X.XXX 4 PID Display = .XXXX | Applies to P204, P205, P214, P215, P231...P233, P242, P522, P523 |
| P203 | PID Units | 0 | 0 % 1 /UNITS 2 AMPS 3 NONE | Select the UNITS LED that will be illuminated when the drive is running in PID control mode |

(2) Parameter currently applicable to ALL SMV models rated at 15 Hp (11.0 kW) and higher

Commissioning



| Code | | Possible Settings | | | | IMPORTANT |
|------|--|-------------------|---|----------------------------------|-----------|---|
| No. | Name | Default | Selection | | | |
| P204 | Feedback at Minimum Signal | 0.0 | -99.9 | | 3100.0 | Set to match the range of the feedback signal being used |
| P205 | Feedback at Maximum Signal | 100.0 | -99.9 | | 3100.0 | Example: Feedback signal is 0 - 300 PSI; P204 = 0.0, P205 = 300.0 |
| P207 | Proportional Gain | 5.0 | 0.0 | {%} | 100.0 | Used to tune the PID loop: <ul style="list-style-type: none"> • Increase P207 until system becomes unstable, then decrease P207 by 10-15% • Next, increase P208 until feedback matches setpoint • If required, increase P209 to compensate for sudden changes in feedback |
| P208 | Integral Gain | 0.0 | 0.0 | {s} | 20.0 | |
| P209 | Derivative Gain | 0.0 | 0.0 | {s} | 20.0 | |
| | | |  NOTE <ul style="list-style-type: none"> • Derivative Gain is very sensitive to noise on the feedback signal and must be used with care • Derivative Gain is not normally required in pump and fan applications | | | |
| P210 | PID Setpoint Ramp | 20.0 | 0.0 | {s} | 100.0 | <ul style="list-style-type: none"> • time of setpoint change from P204 to P205 or vice versa. • Used to smooth the transition from one PID setpoint to another, such as when using the Preset PID Setpoints (P231...P233) |
| P214 | Minimum Alarm | 0.0 | P204 | | P205 | Use with P140, P142 = 18...23 |
| P215 | Maximum Alarm | 0.0 | P204 | | P205 | |
| P231 | Preset PID Setpoint #1 | 0.0 | P204 | | P205 | TB-13A activated; P121 = 3 and P200 = 1 or 2 |
| P232 | Preset PID Setpoint #2 | 0.0 | P204 | | P205 | TB-13B activated; P122 = 3 and P200 = 1 or 2 |
| P233 | Preset PID Setpoint #3 | 0.0 | P204 | | P205 | TB-13C activated; P123 = 3 and P200 = 1 or 2 |
| P240 | Sleep Threshold | 0.0 | 0.0 | {Hz} | 500.0 | <ul style="list-style-type: none"> • If drive speed < P240 for longer than P241, output frequency = 0.0 Hz; drive display = SLP • P240 = 0.0: Sleep mode is disabled. • P200 = 0...2: Drive will start again when speed command is above P240 • P242 > 0.0: Drive will restart when the PID feedback differs from the setpoint by more than the value of P242 or when the PID loop requires a speed above P240. |
| P241 | Sleep Delay | 30.0 | 0.0 | {s} | 300.0 | |
| P242 | Sleep Bandwidth | 0.0 | 0.0 | | B_{max} | |
| | | | Where: $B_{max} = (P205 - P204) $ | | | |
| P243 | Feedback Sleep Entry Threshold | 0.0 | P204 | | P205 | Active only when P244 = 1 or 2 |
| P244 | Sleep Entry Mode | 0 | 0 | Enter SLEEP if Drive Speed <P240 | | For time longer than P241 |
| | | | 1 | Enter SLEEP if Feedback >P243 | | For time longer than P241 or same as Sel 0 |
| | | | 2 | Enter SLEEP if Feedback <P243 | | For time longer than P241 or same as Sel 0 |
| P245 | Sleep Entry Stop Type | 0 | 0 | Coast to Stop | | |
| | | | 1 | Ramp to Stop | | |
| | | | 2 | Stop with P111 settings | | |
| P246 | Feedback Recovery from Sleep Threshold | 0.0 | P204 | | P205 | Active only when P246 = 1 or 2 |

(2) Parameter currently applicable to ALL SMV models rated at 15 Hp (11.0 kW) and higher



Commissioning

| Code | | Possible Settings | | | IMPORTANT | |
|--|--------------------------------|-------------------|-----------|--|---|--|
| No. | Name | Default | Selection | | | |
| P247 | Sleep Recovery Mode | 0 | 0 | Recovery if Speed Setpoint > P240 or if PID feedback differs from setpoint by more than P242 | | |
| | | | 1 | Recovery only if Feedback < P246 | | |
| | | | 2 | Recovery only if Feedback > P246 | | |
| P250 | Auto Rinse in Sleep Mode | 0 | 0 | Disabled | Activated in sleep mode only. Sleep Recovery cancels Auto Rinse | |
| | | | 1 | Enabled | | |
| P251 | Time Delay between Auto Rinses | 30.0 | 0.0 | {min} | 6553.5 | Time delay reset by re/entering sleep mode |
| P252 | Auto Rinse Speed | 0.0 | -500.0 | {Hz} | 500.0 | If P112 = 1, negative sign = reverse direction |
| P253 | Auto Rinse Time | 0.0 | 0.0 | {sec} | 6553.5 | Does not include time to decel back to speed |
| Auto Pump Rinse Setup: P250=1 (Enabled) P251=# minutes between each PumpRinse P252=Hz speed of Pump Rinse P253=# seconds Pump Rinse duration | | | | | | |

4.5.5 Vector Parameters



| Code | | Possible Settings | | | IMPORTANT |
|----------|------------|-------------------|---|------------------------|---|
| No. | Name | Default | Selection | | |
| P300 (1) | Drive Mode | 0 | 0 | Constant V/Hz | Constant torque V/Hz control for general applications |
| | | | 1 | Variable V/Hz | Variable torque V/Hz control for centrifugal pump and fan applications |
| | | | 2 | Enhanced Constant V/Hz | For single or multiple motor applications that require better performance than settings 0 or 1, but cannot use Vector mode, due to: |
| | | | 3 | Enhanced Variable V/Hz | |
| | | | 4 | Vector Speed | For single-motor applications requiring higher starting torque and speed regulation |
| | | | 5 | Vector Torque | For single-motor applications requiring torque control independent of speed |
| | | | i NOTE To configure the drive for either Vector mode or Enhanced V/Hz mode: <ul style="list-style-type: none"> • P300 = 4, 5: <ul style="list-style-type: none"> - Set P302...P306 according to motor nameplate - Set P399 = 1 - Make sure motor is cold (20° - 25° C) and apply a Start command - Display will indicate Cal for about 40 seconds - Once the calibration is complete, the display will indicate Stop; apply another Start command to actually start the motor - If an attempt is made to start the drive in Vector or Enhanced V/Hz mode before performing the Motor Calibration, the drive will display F.r Id and will not operate • P300 = 2, 3: Same as above but only need to set P302...P304 | | |

(1) Any changes to this parameter will not take effect until the drive is stopped

(2) Parameter currently applicable to ALL SMV models rated at 15 Hp (11.0 kW) and higher

Commissioning



| Code | | Possible Settings | | | | IMPORTANT |
|---------------------|-----------------------------------|---|---|----------------------|-------|---|
| No. | Name | Default | Selection | | | |
| P302 ⁽¹⁾ | Motor Rated Voltage | | 0 | {V} | 600 | <ul style="list-style-type: none"> • Default setting = drive rating • Set to motor nameplate data |
| P303 ⁽¹⁾ | Motor Rated Current | | 0.0 | {A} | 500.0 | |
| P304 ⁽¹⁾ | Motor Rated Frequency | 60 | 0 | {Hz} | 1000 | Set to motor nameplate data |
| P305 ⁽¹⁾ | Motor Rated Speed | 1750 | 300 | {RPM} | 65000 | |
| P306 ⁽¹⁾ | Motor Cosine Phi | 0.80 | 0.40 | | 0.99 | |
| | |  | NOTE If motor cosine phi is not known, use one of the following formulas: $\cos \phi = \text{motor Watts} / (\text{motor efficiency} \times P302 \times P303 \times 1.732)$ $\cos \phi = \cos [\sin^{-1} (\text{magnetizing current} / \text{motor current})]$ | | | |
| P310 ⁽¹⁾ | Motor Stator Resistance | 0.00 | 0.00 | { Ω } | 64.00 | <ul style="list-style-type: none"> • Will be automatically programmed by P399 • Changing these settings can adversely affect performance. Contact factory technical support prior to changing |
| P311 ⁽¹⁾ | Motor Stator Inductance | 0.0 | 0.0 | {mH} | 2000 | |
| P330 | Torque Limit | 100 | 0 | {%} | 400 | When P300 = 5, sets the maximum output torque. |
| P331 | Preset Torque Setpoint #1 | 100 | 0 | {%} | 400 | TB-13A activated; P121 = 3 and P300 = 5 |
| P332 | Preset Torque Setpoint #2 | 100 | 0 | {%} | 400 | TB-13B activated; P122 = 3 and P300 = 5 |
| P333 | Preset Torque Setpoint #3 | 100 | 0 | {%} | 400 | TB-13C activated; P123 = 3 and P300 = 5 |
| P340 ⁽¹⁾ | Current Loop P Gain | 0.25 | 0.00 | | 16.0 | Changing these settings can adversely affect performance. Contact factory technical support prior to changing. |
| P341 ⁽¹⁾ | Current Loop I Gain | 65 | 12 | {ms} | 9990 | |
| P342 ⁽¹⁾ | Speed Loop Adjust | 0.0 | 0.0 | {%} | 20.0 | |
| P343 ⁽²⁾ | Slip Compensation Response Filter | 99 | 90 | {ms} | 9999 | Low pass filter time constant for varying the slip compensation response to changes in the motor current. |
| P399 | Motor Auto-calibration | 0 | 0 | Calibration Not Done | | <ul style="list-style-type: none"> • If P300 = 2...5, motor calibration must be performed, but motor data must be programmed first • An alternating CAL / Err will occur if: <ul style="list-style-type: none"> - motor calibration is attempted with P300 = 0 or 1 - motor calibration is attempted before programming motor data |
| | | | 1 | Calibration Enabled | | |
| | | | 2 | Calibration Complete | | |
| | |  | NOTE: To run the Auto Calibration: <ul style="list-style-type: none"> - Set P302...P306 according to motor nameplate - Set P399 = 1 - Make sure motor is cold (20° - 25° C) - Apply a Start command - Display will indicate CAL for about 40 seconds - Once the calibration is complete, the display will indicate Stop; apply another Start command to actually start the motor - Parameter P399 will now be set to 2. | | | |

(1) Any changes to this parameter will not take effect until the drive is stopped

(2) Parameter currently applicable to ALL SMV models rated at 15 Hp (11.0 kW) and higher



Commissioning

4.5.6 Network Parameters

| Code | | Possible Settings | | IMPORTANT |
|---------------|------------------|----------------------------|--|---|
| No. | Name | Default | Selection | |
| P400 | Network Protocol | | 0 Not Active 1 Remote Keypad 2 Modbus RTU 3 CANopen 4 DeviceNet 5 Ethernet 6 Profibus 7 Lecom-B 8 I/O Module | This parameter setting is based upon the network or I/O module that is installed. |
| P401 ... P499 | | Module Specific Parameters | | |

4.5.7 Diagnostic Parameters

| Code | | Display Range (READ ONLY) | | | IMPORTANT |
|------|-------------------------|---------------------------|-------|---------|--|
| No. | Name | | | | |
| P500 | Fault History | | | | <ul style="list-style-type: none"> Displays the last 8 faults Format: n.xxx where: n = 1..8, 1 is the newest fault xxx = fault message (without the F.) Refer to section 5.3 |
| P501 | Software Version | | | | Format: x.yz |
| P502 | Drive ID | | | | A flashing display indicates that the Drive ID stored in the EPM does not match the drive model it is plugged into. |
| P503 | Internal Code | | | | Alternating Display: xxx-; -yy |
| P505 | DC Bus Voltage | 0 | {VDC} | 1500 | |
| P506 | Motor Voltage | 0 | {VAC} | 1000 | |
| P507 | Load | 0 | {%} | 255 | Motor load as % of drive's output current rating. Refer to section 2.3. |
| P508 | Motor Current | 0.0 | {A} | 1000 | Actual motor current |
| P509 | Torque | 0 | {%} | 500 | Torque as % of motor rated torque (vector mode only) |
| P510 | kW | 0.00 | {kW} | 650.0 | |
| P511 | kWh | 0.0 | {kWh} | 9999999 | Alternating display: xxx-; yyyy when value exceeds 9999 |
| P512 | Heatsink Temp | 0 | {°C} | 150 | Heatsink temperature |
| P520 | 0-10 VDC Input | 0.0 | {VDC} | 10.0 | Actual value of signal at TB-5 |
| P521 | 4-20 mA Input | 0.0 | {mA} | 20.0 | Actual value of signal at TB-25 |
| P522 | TB-5 Feedback | P204 | | P205 | TB-5 signal value scaled to PID feedback units |
| P523 | TB-25 Feedback | P204 | | P205 | TB-25 signal value scaled to PID feedback units |
| P525 | Analog Output | 0 | {VDC} | 10.0 | Refer to P150...P155 |
| P527 | Actual Output Frequency | 0 | {Hz} | 500.0 | |
| P528 | Network Speed Command | 0 | {Hz} | 500.0 | Command speed if (Auto: Network) is selected as the speed source |




| Code | | Display Range (READ ONLY) | | IMPORTANT |
|------|--------------------------------|---------------------------|-------------|--|
| No. | Name | | | |
| P530 | Terminal and Protection Status | | | Indicates terminal status using segments of the LED display. (Refer to section 4.5.7.1) |
| P531 | Keypad Status | | | Indicates keypad button status using segments of the LED display. (Refer to section 4.5.7.2) |
| P540 | Total Run Time | 0 | {h} 9999999 | Alternating display: xxx-; yyyy when value exceeds 9999 |
| P541 | Total Power On Time | 0 | {h} 9999999 | |

4.5.7.1 Terminal & Protection Status Display

Parameter P530 allows monitoring of the control terminal points and common drive conditions:

An illuminated LED segment indicates:

- the protective circuit is active (LED 1)
- the Logic Assertion Switch is set to High (+)
- input terminal is asserted (LED 2)
- output terminal is energized (LED 4)
- the Charge Relay is not a terminal, this segment will be illuminated when the Charge Relay is energized (LED 4).




* Input 13D available on 15-30HP (11-22kW) models only

4.5.7.2 Keypad Status Display

Parameter P531 allows monitoring of the keypad pushbuttons:

An illuminated LED segment indicates when the button is depressed.

LED 1 and LED 2 are used to indicate pushbutton presses on a remote keypad that is attached to the drive. LED 3 and LED 4 indicate button presses on the local drive keypad.





Commissioning

4.5.8 Onboard Communications Parameters 15-30HP (11-22kW)

The P6xx Onboard Communication parameters are applicable to the 15HP (11kW) and greater models only.

| Code | | Possible Settings | | IMPORTANT |
|------|------------------------------|-------------------|---|--|
| No. | Name | Default | Selection | |
| P600 | Network Enable | 0 | 0 Disabled 1 Remote Keypad 2 Modbus 7 Lecom | This parameter enables the onboard network communications. If the onboard communications are disabled, the user will not have access to any of the other P6xx parameters. |
| | | | NOTE: Onboard Communications will be disabled if: - P600 = 0, or - P600 = 1 and P400 = 1, or - P600 = 2 and P400 = 2, 3, 4, 5, 6 or 7 - P600 = 7 and P400 = 2, 3, 4, 5, 6 or 7 | |
| P610 | Network Address | 1 | 1 - 247 | Modbus |
| | | 1 | 1 - 99 | Lecom |
| P611 | Network Baud Rate | 2 | 0 2400 bps 2 9600 bps 1 4800 bps 3 19200 bps | Modbus |
| | | 0 | 0 9600 bps 1 4800 bps 2 2400 bps 3 1200 bps 4 19200 bps | Lecom |
| P612 | Network Data Format | 0 | 0 8, N, 2 1 8, N, 1 2 8, E, 1 3 8, 0, 1 | Modbus Only |
| | | | | |
| P620 | Network Control Level | 0 | 0 Monitor Only 1 Parameter Programming 2 Programming and Setpoint Control 3 Full Control | Lecom Only |
| P624 | Network Powerup Start Status | 0 | 0 Quick Stop 1 Controller Inhibit | Lecom Only |
| P625 | Network Timeout | 10.0 | 0.0 - 300.0 seconds | Modbus |
| | | 50 | 0 - 65000 milliseconds | Lecom |
| P626 | Network Timeout Action | 4 | 0 No action 1 Stop (P111) 2 Quick Stop 3 Controller Inhibit 4 Trip Fault, F.nF1 | Modbus |
| | | 0 | 0 No action 1 Controller Inhibit 2 Quick Stop 3 Trip Fault, F.nF1 | Lecom |
| P627 | Network Messages Received | | Read-Only: 0 - 9999 NOTE: When the number of messages exceeds 9999, the counter resets and resumes counting from 0. | Valid network messages received |



5 Troubleshooting and Diagnostics

5.1 Status/Warning Messages

| | Status / Warning | Cause | Remedy |
|-------------|---|---|---|
| br | DC-injection brake active | DC-injection brake activated <ul style="list-style-type: none"> activation of digital input (P121...P124 = 18) automatically (P110 = 2, 4...6) automatically (P111 = 1, 3) | Deactivate DC-injection brake <ul style="list-style-type: none"> deactivate digital input automatically after P175 time has expired |
| bF | Drive ID warning | The Drive ID (P502) stored on the EPM does not match the drive model. | <ul style="list-style-type: none"> Verify motor data (P302...P306) and perform Auto Calibration. Set drive mode (P300) to 0 or 1 Reset the drive (P199 to 3 or 4) and reprogram. |
| CRl | Motor Auto-calibration active | Refer to P300, P399 | Motor Auto-calibration is being performed |
| cE | An EPM that contains valid data from a previous software version has been installed | An attempt was made to change parameter settings | Parameter settings can only be changed after the EPM data is converted to the current version (P199 = 5) |
| CL | Current Limit (P171) reached | Motor overload | <ul style="list-style-type: none"> Increase P171 Verify drive/motor are proper size for application |
| dEC | Decel Override | The drive has stopped decelerating to avoid tripping into HF fault, due to excessive motor regen (2 sec max). | If drive trips into HF fault: <ul style="list-style-type: none"> Increase P105, P126 Install Dynamic Braking option |
| Errr | Error | Invalid data was entered, or an invalid command was attempted | |
| FCL | Fast Current Limit | Overload | Verify drive/motor are proper size for application |
| FSt | Flying Restart Attempt after Fault | P110 = 5,6 | |
| GE | OEM Settings Operation warning | An attempt was made to change parameter settings while the drive is operating in OEM Settings mode. | In OEM Settings mode (P199 = 1), making changes to parameters is not permitted. |
| GF | OEM Defaults data warning | An attempt was made to use (or reset to) the OEM default settings (P199 = 1 or 2) using an EPM without valid OEM data. | Install an EPM containing valid OEM Defaults data |
| LC | Fault Lockout | The drive attempted 5 restarts after a fault but all attempts were unsuccessful (P110 = 3...6) | <ul style="list-style-type: none"> Drive requires manual reset Check Fault History (P500) and correct fault condition |
| PdEC | PID Deceleration Status | PID setpoint has finished its ramp but the drive is still decelerating to a stop. | |
| PI d | PID Mode Active | Drive has been put into PID Mode. | Refer to P200 |
| SLP | Sleep Mode is active | Refer to P240...P242 | |
| SP | Start Pending | The drive has tripped into a fault and will automatically restart (P110 = 3...6) | To disable Auto-Restart, set P110 = 0...2 |
| SPd | PID Mode disabled. | Drive has been taken out of PID Mode. Refer to P200. | |
| StoP | Output frequency = 0 Hz (outputs U, V, W inhibited) | Stop has been commanded from the keypad, terminal strip, or network | Apply Start command (Start Control source depends on P100) |



Troubleshooting and Diagnostics

5.2 Drive Configuration Messages

When the Mode button is pressed and held, the drive's display will provide a 4-digit code that indicates how the drive is configured. If the drive is in a Stop state when this is done, the display will also indicate which control source commanded the drive to Stop (the two displays will alternate every second).

| Configuration Display | | | |
|-----------------------|---|--|--|
| Format = x.y.zz | x = Control Source: L = Local Keypad t = Terminal Strip r = Remote Keypad n = Network | y = Mode: S = Speed mode P = PID mode t = Vector Torque mode | zz = Reference: CP = Keypad ▲ ▼ EU = 0-10 VDC (TB-5) EI = 4-20 mA (TB-25) JG = Jog nE = Network DP = MOP P L...P7 = Preset 1...7 |
| | Example: <ul style="list-style-type: none"> L_S_CP = Local Keypad Start control, Speed mode, Keypad speed reference t_P_EU = Terminal Strip Start control, PID mode, 0-10 VDC setpoint reference n_t_PP = Network Start control, Vector Torque mode, Preset Torque #2 reference | | |
| Stop Source Display | | | |
| Format = x_5tP | L_5tP = Stop command came from Local Keypad t_5tP = Stop command came from Terminal Strip r_5tP = Stop command came from Remote Keypad n_5tP = Stop command came from Network | | |

5.3 Fault Messages

The messages below show how they will appear on the display when the drive trips. When looking at the Fault History (P500), the F_ will not appear in the fault message.

| Fault | Cause | Remedy ⁽¹⁾ |
|-------|------------------------|--|
| F_Rf | High Temperature fault | Drive is too hot inside |
| F_RL | Assertion Level fault | <ul style="list-style-type: none"> Assertion Level switch is changed during operation P120 is changed during operation P100 or P121...P124 are set to a value other than 0 and P120 does not match the Assertion Level Switch. |
| F_bF | Personality fault | Drive Hardware |
| F_cF | Control fault | An EPM has been installed that is either blank or corrupted |
| F_cF | Incompatible EPM fault | An EPM has been installed that contains data from an incompatible parameter version |
| | | <ul style="list-style-type: none"> Reduce drive load Improve cooling Make sure the Assertion Level switch and P120 are both set for the type of input devices being used, prior to setting P100 or P121...P124. Refer to 3.2.3 and P120. Cycle Power Power down and install EPM with valid data Reset the drive back to defaults (P199 = 3, 4) and then re-program If problem persists, contact factory technical support |

(1) The drive can only be restarted if the error message has been reset.



| Fault | | Cause | Remedy ⁽¹⁾ |
|--------------------|---|--|--|
| F_dbF | Dynamic Braking fault | Dynamic braking resistors are overheating | <ul style="list-style-type: none"> • Increase active decel time (P105, P126, P127). • Check mains voltage and P107 |
| F_EF | External fault | <ul style="list-style-type: none"> • P121...P124 = 21 and that digital input has been opened. • P121...P124 = 22 and that digital input has been closed. | <ul style="list-style-type: none"> • Correct the external fault condition • Make sure digital input is set properly for NC or NO circuit |
| F_F I | EPM fault | EPM missing or defective | Power down and replace EPM |
| F_F2 ... | Internal faults | | Contact factory technical support |
| F_F I2 | Control Configuration Fault | The drive is setup for REMOTE KEYPAD control (P100=2 or 5) but is not setup to communicate with a remote keypad | Set P400 = 1, or P600 = 1 |
| F_Fnr | | The drive is setup for NETWORK ONLY control (P100=3) but is not setup for network communications | Set P400 or P600 to a valid network communications protocol selection |
| F_FaL | Loss of 4-20 mA signal fault | 4-20 mA signal (at TB-25) is below 2 mA (P163 = 1) | Check signal/signal wire |
| F_GF | OEM Defaults data fault | Drive is powered up with P199 = 1 and OEM settings in the EPM are not valid. | Install an EPM containing valid OEM Defaults data or change P199 to 0. |
| F_HF | High DC Bus Voltage fault | Mains voltage is too high | Check mains voltage and P107 |
| | | Decel time is too short, or too much regen from motor | Increase active decel time (P105, P126, P127) or install Dynamic Braking option |
| F_IL | Digital Input Configuration fault (P121...P124) | More than one digital input set for the same function | Each setting can only be used once (except settings 0 and 3) |
| | | Only one digital input configured for MOP function (Up, Down) | One input must be set to MOP Up, another must be set to MOP Down |
| | | PID mode is entered with setpoint reference and feedback source set to the same analog signal | Change PID setpoint reference (P121...P124) or feedback source (P201). |
| | | One of the digital inputs (P121...P124) is set to 10 and another is set to 11...14. | Reconfigure digital inputs |
| | | One of the digital inputs (P121...P124) is set to 11 or 12 and another is set to 13 or 14. | |
| | | PID enabled in Vector Torque mode (P200 = 1 or 2 and P300 = 5) | PID cannot be used in Vector Torque mode |
| F_JF | Remote keypad fault | Remote keypad disconnected | Check remote keypad connections |
| F_LF | Low DC Bus Voltage fault | Mains voltage too low | Check mains voltage |
| F_n Id | No Motor ID fault | An attempt was made to start the drive in Vector or Enhanced V/Hz mode prior to performing the Motor Auto-calibration | See P300...P399 for Drive Mode setup and calibration. |
| F_n tF | Module communication fault | Communication failure between drive and Network Module. | Check module connections |

(1) The drive can only be restarted if the error message has been reset.



Troubleshooting and Diagnostics

| Fault | | Cause | Remedy ⁽¹⁾ |
|--------------------------------------|-----------------------------------|---|--|
| F_nF I ... F_nF9 | Network Faults | Refer to the module documentation. for Causes and Remedies. | |
| F_DF | Output fault: Transistor fault | Output short circuit | Check motor/motor cable |
| | | Acceleration time too short | Increase P104, P125 |
| | | Severe motor overload, due to: <ul style="list-style-type: none">• Mechanical problem• Drive/motor too small for application | <ul style="list-style-type: none">• Check machine / system• Verify drive/motor are proper size for application |
| | | Boost values too high | Decrease P168, P169 |
| | | Excessive capacitive charging current of the motor cable | <ul style="list-style-type: none">• Use shorter motor cables with lower charging current• Use low capacitance motor cables• Install reactor between motor and drive. |
| | Failed output transistor | Contact factory technical support | |
| F_QF I | Output fault: Ground fault | Grounded motor phase | Check motor and motor cable |
| | | Excessive capacitive charging current of the motor cable | Use shorter motor cables with lower charging current |
| F_PF | Motor Overload fault | Excessive motor load for too long | <ul style="list-style-type: none">• Verify proper setting of P108• Verify drive and motor are proper size for application |
| F_rF | Flying Restart fault | Controller was unable to synchronize with the motor during restart attempt; (P110 = 5 or 6) | Check motor / load |
| F_SF | Single-Phase fault | A mains phase has been lost | Check mains voltage |
| F_UF | Start fault | Start command was present when power was applied (P110 = 0 or 2). | <ul style="list-style-type: none">• Must wait at least 2 seconds after power-up to apply Start command• Consider alternate starting method (refer to P110). |

(1) The drive can only be restarted if the error message has been reset.



Appendix A

A.1 Permissible Cable Lengths

The table herein lists the permissible cable lengths for use with an SMV inverter with an internal EMC filter.



NOTE

This table is intended as a reference guideline only; application results may vary. The values in this table are based on testing with commonly available low-capacitance shielded cable and commonly available AC induction motors. Testing is conducted at worst case speeds and loads.

| Maximum Permissible Cable Lengths (Meters) for SMV Model with Internal EMC Filters | | | | | | | | | |
|--|------------------------------|-----------------------------|---------|-----------------------------|---------|-----------------------------|---------|------------------------------|---------|
| Mains | Model | 4 kHz Carrier (P166 = 0) | | 6 kHz Carrier (P166 = 1) | | 8 kHz Carrier (P166 = 2) | | 10 kHz Carrier (P166 = 3) | |
| | | Class A | Class B | Class A | Class B | Class A | Class B | Class A | Class B |
| 240 V, 1-phase (2/PE) | ESV251 $\phi\phi$ 2SF ϕ | 38 | 12 | 35 | 10 | 33 | 5 | 30 | N/A |
| | ESV371 $\phi\phi$ 2SF ϕ | 38 | 12 | 35 | 10 | 33 | 5 | 30 | N/A |
| | ESV751 $\phi\phi$ 2SF ϕ | 38 | 12 | 35 | 10 | 33 | 5 | 30 | N/A |
| | ESV112 $\phi\phi$ 2SF ϕ | 38 | 12 | 35 | 10 | 33 | 5 | 30 | N/A |
| | ESV152 $\phi\phi$ 2SF ϕ | 38 | 12 | 35 | 10 | 33 | 5 | 30 | N/A |
| | ESV222 $\phi\phi$ 2SF ϕ | 38 | 12 | 35 | 10 | 33 | 5 | 30 | N/A |
| 400/480 V, 3-phase (3/PE) | ESV371 $\phi\phi$ 4TF ϕ | 30 | 4 | 25 | 2 | 20 | N/A | 10 | N/A |
| | ESV751 $\phi\phi$ 4TF ϕ | 30 | 4 | 25 | 2 | 20 | N/A | 10 | N/A |
| | ESV112 $\phi\phi$ 4TF ϕ | 30 | 4 | 25 | 2 | 20 | N/A | 10 | N/A |
| | ESV152 $\phi\phi$ 4TF ϕ | 30 | 4 | 25 | 2 | 20 | N/A | 10 | N/A |
| | ESV222 $\phi\phi$ 4TF ϕ | 30 | 4 | 25 | 2 | 20 | N/A | 10 | N/A |
| | ESV302 $\phi\phi$ 4TF ϕ | 30 | 4 | 25 | 2 | 20 | N/A | 10 | N/A |
| | ESV402 $\phi\phi$ 4TF ϕ | 54 | 5 | 48 | 3 | 42 | 2 | N/A | N/A |
| | ESV552 $\phi\phi$ 4TF ϕ | 54 | 5 | 48 | 3 | 42 | 2 | N/A | N/A |
| | ESV752 $\phi\phi$ 4TF ϕ | 54 | 5 | 48 | 3 | 42 | 2 | N/A | N/A |

NOTE: The “ $\phi\phi$ ” and “ ϕ ” symbols are place holders in the Model part number that contain different information depending on the specific configuration of the model. Refer to the SMV Type Number Designation table in section 2.2 for more information.

Lenze AC Tech Corporation

630 Douglas Street • Uxbridge, MA 01569 • USA

Sales: 800 217-9100 • Service: 508 278-9100

www.lenze-actech.com

(SV01J-e1)